

# Change Administrative State of ECLI, NETCONF, or FTP over TLS

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Change Administrative State of ECLI over TLS	1
2.2	Change Administrative State of NETCONF over TLS	2
2.3	Change Administrative State of FTP over TLS	3



Change Administrative State of ECLI, NETCONF, or FTP over TLS



# 1 Description

This instruction describes how to change the administrative state of ECLI, NETCONF, or FTP over TLS.

## 2 Procedure

### 2.1 Change Administrative State of ECLI over TLS

#### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The user has the System Security Administrator role.
  - At least one of the administrative states, ECLI over TLS or NETCONF over TLS, must be unlocked.
  - An Ericsson Command-Line Interface (ECLI) in exec mode is in progress.

---

---

#### Attention!



Risk of system malfunction or traffic disturbance.

---

---

Before locking the administrative state of ECLI over TLS, make sure that the administrative state of NETCONF over TLS is UNLOCKED. Having both interfaces set to LOCKED disables O&M access to the ME. Refer to product-specific troubleshooting instructions to resolve such a scenario.

#### Steps

1. Navigate to the CliTIs Managed Object (MO), for example:



```
>dn ManagedElement=1,SystemFunctions=1,SysM=1,CliTls=1
```

2. Enter Config mode:

```
(CliTls=1)>configure
```

3. Set the administrativeState attribute, for example:

```
(config-CliTls=1)>administrativeState=UNLOCKED
```

**Note:** To lock the administrative state, set the attribute value to LOCKED.

4. Commit the settings:

```
(config-CliTls=1)>commit
```

5. Verify the settings:

```
(CliTls=1)>show
```

The following is an example output:

```
CliTls=1
[...]
administrativeState=UNLOCKED
```

## 2.2 Change Administrative State of NETCONF over TLS

### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The user has the System Security Administrator role.
  - At least one of the administrative states, ECLI over TLS or NETCONF over TLS, must be unlocked.
  - An Ericsson Command-Line Interface (ECLI) in exec mode is in progress.



---

---

### Attention!

Risk of system malfunction or traffic disturbance.

---

---



Before locking the administrative state of ECLI over TLS, make sure that the administrative state of NETCONF over TLS is UNLOCKED. Having both interfaces set to LOCKED disables O&M access to the ME. Refer to product-specific troubleshooting instructions to resolve such a scenario.

### Steps

1. Navigate to the `NetconfTls` Managed Object (MO), for example:

```
>dn ManagedElement=1,SystemFunctions=1,SysM=1,NetconfTls=1
```

2. Enter Config mode:

```
(NetconfTls=1)>configure
```

3. Set the `administrativeState` attribute, for example:

```
(config-NetconfTls=1)>administrativeState=UNLOCKED
```

**Note:** To lock the administrative state, set the attribute value to LOCKED.

4. Commit the settings:

```
(config-NetconfTls=1)>commit
```

5. Verify the settings:

```
(NetconfTls=1)>show
```

The following is an example output:

```
NetconfTls=1
[...]
administrativeState=UNLOCKED
```

## 2.3 Change Administrative State of FTP over TLS

### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The user has the System Security Administrator role.
  - An Ericsson Command-Line Interface (ECLI) in exec mode is in progress.



---

## Attention!

Risk of system malfunction or traffic disturbance.

---

Before locking the administrative state of FTP over TLS, make sure that the FTP-server is not used. The change of state closes all ongoing FTP connections.

### Steps

1. Navigate to the `FtpTlsServer` Managed Object (MO), for example:

```
>dn ManagedElement=1,SystemFunctions=1,SysM=1,FileTPM=1,FtpServer=1,FtpTlsServer=1
```

2. Enter Config mode:

```
(FtpTlsServer=1)>configure
```

3. Set the `administrativeState` attribute, for example:

```
(config-FtpTlsServer=1)>administrativeState=UNLOCKED
```

**Note:** To lock the administrative state, set the attribute value to `LOCKED`.

4. Commit the settings:

```
(config-FtpTlsServer=1)>commit
```

5. Verify the settings:

```
(FtpTlsServer=1)>show
```

The following is an example output:

```
FtpTlsServer=1
[...]
    administrativeState=UNLOCKED
```