

# Cancel Backup and Restore Operation

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Cancel Backup and Restore Operation	1



Cancel Backup and Restore Operation



# 1 Description

This instruction describes how to cancel a backup and restore operation.

## 2 Procedure

### 2.1 Cancel Backup and Restore Operation

#### Prerequisites

- No documents are required.
- No tools are required.
- The following condition must apply:
  - A backup and restore operation is in progress.
  - The backup and restore name is known.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. Navigate to the `BrMBackupManager` managed object, for example:  

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,BrM=1,BrMBackupManager=SYSTEM_DATA
```
2. Select the appropriate action:
  - Cancel a create operation, delete operation, or import operation: Proceed with Step 3.
  - Cancel a restore or export operation: Process with Step 6.
3. Cancel the create operation, delete operation, or import operation:  

```
(BrMBackupManager=SYSTEM_DATA)>cancelCurrentAction
```

The system returns output `true` or `false`.
4. Verify that the operation was canceled:



```
(BrmBackupManager=SYSTEM_DATA)>show -v
```

**Note:** It can be required to enter the command several times until result=SUCCESS is shown in the progress report.

5. Proceed with Step 9.
6. Navigate to the `BrmBackup` MO, for example:

```
(BrmBackupManager=SYSTEM_DATA)>BrmBackup=PERF_BACKUP_NAME1_20140428_175907
```

7. Cancel the restore or export operation:

```
(BrmBackup=PERF_BACKUP_NAME1_20140428_175907)>cancelCurrentAction
```

The system returns output true or false.

8. Verify that the operation was canceled:

```
(BrmBackup=PERF_BACKUP_NAME1_20140428_175907)>show -v
```

**Note:** It can be required to enter the command several times until state=CANCELLED is shown in the progress report.

9. After an operation is successfully canceled, the progress report shows the following when a create operation has been canceled:

```
actionName="CREATE" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="Backup Object [PERF_BACKUP_NAME1_20140428_175907] was successfully deleted" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when a delete operation has been canceled:

```
actionName="DELETE" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when an import operation has been canceled:



```
actionName="IMPORT" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when a restore operation has been canceled:

```
actionName="RESTORE" <read-only>
additionalInfo
  "CANCEL_PHASE is completed"
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when an export operation has been canceled:

```
actionName="EXPORT" <read-only>
additionalInfo
  "CANCEL_PHASE is completed"
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

If an error occurs during the execution of the action, attribute `reportProgress` shows `result=FAILURE` and `resultInfo` shows the cause of the failure.

For more information on the progress report, refer to [View Progress Report](#).