

Delete User Account

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2015, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

| | | |
|----------|---------------------|----------|
| 1 | Description | 1 |
| 2 | Procedure | 1 |
| 2.1 | Delete User Account | 1 |



Delete User Account



1 Description

This instruction describes how to delete a local Operation and Maintenance (O&M) user account.

2 Procedure

2.1 Delete User Account

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The user has sufficient access rights to perform the task, for example, the user has System Security Administrator role.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.
 - The username for the local user account is known. In this instruction, the username is joedoe.

Steps

1. Navigate to the `UserAccountM` Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,SecM=1,UserManagement=1,LocalAuthenticationMethod=1,UserAccountM=1
```
2. Enter Config mode:

```
(UserAccountM=1)>configure
```
3. Delete the `UserAccount` MO, for example:

```
(config-UserAccountM=1)>no UserAccount=joedoe
```
4. Commit the deletion:

```
(config-UserAccountM=1)>commit
```



5. Verify that no user account for username joedoe exists, for example:

```
(UserAccountM=1)>show UserAccount=joedoe
```

```
ERROR: Specific element not found
```