

# SS7 CAF Link Deactivated

---

## OPERATING INSTRUCTION

**Copyright**

© Ericsson AB 2009-2010, 2013. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.



# Contents

<b>1</b>	<b>Overview</b>	<b>1</b>
1.1	Description	1
1.2	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>



SS7 CAF Link Deactivated



# 1 Overview

## 1.1 Description

The alarm is issued when a signaling link has been deactivated by an operator. It has been taken out of service.

<b>Major type</b>	193
<b>Minor type</b>	1586562568
<b>MO Class</b>	N/A
<b>Specific Problem</b>	Link Deactivated
<b>Severity</b>	SEVERITY_MINOR

The possible causes are as follows:

- An operator has sent the link deactivation order for this link.

No remedial action is required.

## 1.2 Prerequisites

### 1.2.1 Documents

Before starting this procedure, make sure that you have read the following documents:

- "Fault Management User Guide" (24/1553-APR 901 0315/2 Uen)
- "Configuring SS7, System Components" (7/1543-CNA 403 0874/1 Uen)

### 1.2.2 Tools

Not applicable.

### 1.2.3 Conditions

Not applicable.



SS7 CAF Link Deactivated



## 2 Procedure

Perform the following steps:

1. This is a result of the operators actions, a syslog is recorded, and the link is no longer available to traffic.
2. Once dead, links may be reactivated by operator intervention.