

# Unlock LDAP Authentication Method

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>





# 1 Introduction

This document describes how to unlock the LDAP authentication method.

The LDAP authentication method is unlocked when the managed element is operational or to test the proper execution of LDAP authentication.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The procedures in this document are performed either by a System Security Administrator or a local Linux® user belonging to the `com-emergency` group.
- The LDAP administrative state is `LOCKED`.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

**Note:** It is possible to have a user with System Security Administrator role even before unlocking LDAP, if other access control methods are enabled in the ME, for example `LocalAuthentication`.





## 2 Procedure

To unlock the LDAP authentication method:

1. Navigate to the *LdapAuthenticationMethod* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,SecM=1,UserManagement=1,LdapAuthenticationMethod=1
```

2. Enter Config mode:

```
(LdapAuthenticationMethod=1) >configure
```

3. Unlock the LDAP authentication method:

```
(config-LdapAuthenticationMethod=1) >administrativeState=UNLOCKED
```

4. Commit the setting:

```
(config-LdapAuthenticationMethod=1) >commit
```

5. Verify the result:

```
(LdapAuthenticationMethod=1) >show
```

The following is an example output:

```
LdapAuthenticationMethod=1
  administrativeState=UNLOCKED
  Ldap=1
```

The LDAP authentication is now enabled. Users with a security profile in the LDAP server can authenticate with the managed element.