

# Configure Legal Notice

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>





# 1 Introduction

This document describes how to configure the legal notice for Operation and Maintenance (O&M) users. The legal notice is managed by SecM user management and it is displayed when O&M users access the node.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The user has the System Security Administrator role.
- The new legal notice text is known.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.





## 2 Procedure

To configure the legal notice:

1. Navigate to the *UserManagement* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,SecM=1,U  
serManagement=1
```

2. Enter Config mode:

```
(UserManagement=1)>configure
```

3. Set the legal notice text, for example:

```
(config-UserManagement=1)>legalNotice="Only authorized  
users are allowed to access this system.\nTo use the  
system you must agree to the group policies."
```

**Note:** \n can be used as a line break.

4. Commit the setting:

```
(config-UserManagement=1)>commit
```

5. Verify the legalNotice:

```
(UserManagement=1)>show legalNotice
```

The following is an example output:

```
legalNotice="Only authorized users are allowed to access this sy
```