

Schedule Backups Based on Periodic Event

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Schedule Backups Based on Periodic Event	1





1 Description

This instruction describes how to schedule a backup that is to occur at regular intervals.

Note: When any of the following backup operations is in progress, a scheduled backup event that is triggered is postponed and retried at regular intervals later:

- Manual backup creation
- Scheduled backup creation
- Backup deletion
- Backup restore

2 Procedure

2.1 Schedule Backups Based on Periodic Event

Prerequisites

- No documents are required.
- No tools are required.
- The following condition must apply:
 - The event name is known.
 - The periodic event schedule is known.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the *BrmBackupScheduler* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, BrM=1, BrmBackupManager=SYSTEM_DATA, BrmBackupScheduler=SYSTEM_DATA
```



2. Enter Config mode:

```
(BrmBackupScheduler=SYSTEM_DATA) >configure
```

3. Enter the event name, for example:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >BrmPeriodicEvent=P_EVENT_20140428_204
```

4. Create the periodic event by setting the required attributes, for example:

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >days=1
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >hours=5
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >minutes=30
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >weeks=1
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >months=2
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >startTime=2014-06-31T23:59:59
```

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >stopTime=2015-02-28T23:59:59
```

Note: Normally, not all attributes are needed to set.

The value of these attributes cannot be cleared using the `no <attribute_name> ECLI` command.

If Daylight Saving Time (DST) occurs after the scheduling but before the scheduled time (when the backup is created), the timer does not count the minus or plus one hour of time difference. It is the duration of the scheduling interval that matters, not the system clock.

5. Commit the periodic event:

```
(config-BrmPeriodicEvent=P_EVENT_20140428_204) >commit
```

6. Verify that the periodic event was created:

```
(BrmPeriodicEvent=P_EVENT_20140428_204) >show
```

In the following example, outputs of periodic event configuration backups are created every 2 months, 1 week, 1 day, 5 hours, and 30 minutes between 2014-06-31 and 2015-02-28:



```
BrmPeriodicEvent=P_EVENT_20140428_204  
  days=1  
  hours=5  
  minutes=30  
  months=2  
  startTime="2014-06-31T23:59:59"  
  stopTime="2015-02-28T23:59:59"  
  weeks=1
```