

# Delete Enrollment Server Group

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2014, 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>3</b>
2.1	Delete Enrollment Server Group	3



Delete Enrollment Server Group



# 1 Description

This instruction describes how to delete an enrollment server group.



Delete Enrollment Server Group



## 2 Procedure

### 2.1 Delete Enrollment Server Group

#### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The user has the System Security Administrator role.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. Navigate to the *CertM* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, CertM=1
```

2. Enter Config mode:

```
(CertM=1)>configure
```

3. Delete the *EnrollmentServerGroup* MO, for example:

```
(config-CertM=1)>no EnrollmentServerGroup=2
```

4. Commit the change:

```
(config-CertM=1)>commit
```

5. Verify the deletion by checking the *EnrollmentServerGroup* MO instances:

```
(CertM=1)>show -v -r
```

The following is an example output:



```
CertM=1
[...]  
  EnrollmentServerGroup=1  
    enrollmentServerGroupId="1"  
    userLabel=[] <empty>  
    EnrollmentServer=1  
  EnrollmentServerGroup=3  
    enrollmentServerGroupId="3"  
    userLabel=[] <empty>  
    EnrollmentServer=3  
[...]
```