

View Export Log Stream Progress Report

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	View Export Log Stream Progress Report	1



[View Export Log Stream Progress Report](#)



1 Description

This instruction describes how to view the ongoing progress report or the result of the last export operation performed on a registered log stream. There is no historical information about earlier export operation results.

2 Procedure

2.1 View Export Log Stream Progress Report

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - An export operation has been started.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the **Log** managed object, for example:

```
>dn ManagedElement=N0DE06ST,SystemFunctions=1,LogM=1,Log=saLogSystem
```

2. Display the progress report for the operation:

```
(Log=saLogSystem)>show reportProgress
```

The following is an example output:



```
reportProgress
  actionName="EXPORT"
  additionalInfo
    "saLogSystem_20170405_030858.gz is being exported."
  progressInfo=""
  progressPercentage=50
  result=NOT_AVAILABLE
  resultInfo="Export action is running. Please wait for a while!"
  state=RUNNING
  timeActionCompleted="1970-01-01T00:00:00"
  timeActionStarted="2017-04-05T03:08:58"
  timeOfLastStatusUpdate="2017-04-05T03:08:58"
```

Note: Since a long-running operation can be executing, it can be required to enter the command several times until the final operation result is shown in the progress report.

Progress information can be read displaying attributes in `reportProgress`. The progression of the values of important attributes during execution of an export operation is shown in Table 1.

If the operation is successful, subattribute `result=SUCCESS`.

If the operation is unsuccessful, subattribute `result=FAILURE` and subattribute `resultInfo` in attribute `reportProgress` reports an explanatory text message.

Table 1 Progress Values for Main Subattributes

Subattribute Name	Initial Value	Next Value	Next Value	Final Value
progressPercentage	0	25	50	100
state	FINISHED	RUNNING	RUNNING	FINISHED
result	NOT_AVAILABLE	NOT_AVAILABLE	NOT_AVAILABLE	SUCCESS
timeActionCompleted	1970-01-01T01:00:00	1970-01-01T01:00:00	1970-01-01T01:00:00	2017-04-05T03:34:43

Note: Value 1970-01-01T01:00:00 shown for subattribute `timeActionCompleted` is used by default when no real value exists yet.