

# Change User Account

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2015. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>



Change User Account



# 1 Introduction

This document describes how to change attributes in an existing local Operation and Maintenance (O&M) user account.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The user has sufficient access rights to perform the task, for example, the user has System Security Administrator role.
- The user is familiar with the security policy of the organization.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.
- The password policy is known.
- The account policy is known.
- The username (logon ID) for the new local user account is known. In this document, username is `j_oedoe`.
- User account for the username exists.



Change User Account



## 2 Procedure

To change a local O&M user account:

1. Navigate to the *UserAccount* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, UserManagement=1, LocalAuthenticationMethod=1, UserAccountM=1, UserAccount=johndoe
```

2. Enter Config mode:

```
(UserAccount=johndoe) >configure
```

3. Is it required to change account policy for the user account?

Yes: Continue with next step.

No: Proceed with Step 5.

4. Change the account policy for the user account, by setting the reference to the appropriate *AccountPolicy* MO, for example:

```
(config-UserAccount=johndoe) >accountPolicy="ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, UserManagement=1, LocalAuthenticationMethod=1, AccountPolicy=2"
```

5. Is it required to change password policy for the user account?

Yes: Continue with next step.

No: Proceed with Step 7.

6. Change the password policy for the user account, by setting the reference to the appropriate *PasswordPolicy* MO, for example:

```
(config-UserAccount=johndoe) >passwordPolicy="ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, UserManagement=1, LocalAuthenticationMethod=1, PasswordPolicy=2"
```

7. Is it required to change username assigned to the user?

Yes: Continue with next step.

No: Proceed with Step 9.

8. Change the full username assigned to the user, for example:

```
(config-UserAccount=johndoe) >userName="John Matthew Doe"
```



**Note:** This attribute contains a descriptive name of the user, not the logon ID.

9. Commit the settings:

```
(config-UserAccount=joedoe) >commit
```

10. Verify the settings, for example:

```
(UserAccount=joedoe) >show -v
```

The following is an example output:

```
UserAccount=joedoe
  accountPolicy="ManagedElement=NODE06ST,SystemFunctions=1,SecM=
UserManagement=1,LocalAuthenticationMethod=1,AccountPolicy=2"
  accountState=LOCKED <read-only>
  accountUsageState=UNUSED <read-only>
  administrativeState=LOCKED
  lastLoginTime="" <read-only>
  lockedTime="2015-11-13T11:16:19Z" <read-only>
  passwordChangedTime="" <read-only>
  passwordFailureTimes=[] <empty> <read-only>
  passwordPolicy="ManagedElement=NODE06ST,SystemFunctions=1,SecM=
UserManagement=1,LocalAuthenticationMethod=1>PasswordPolicy=2"
  passwordState=[] <empty> <read-only>
  roles
    "SystemAdministrator"
    "EricssonSupport"
  userAccountId="joedoe"
  userLabel=[] <empty>
  userName="John Matthew Doe"
```