

Core 0:	0	10
Core 1:	1	11
Core 2:	2	12
Core 3:	3	13
Core 4:	4	14
Core 5:	5	15
Core 6:	6	16
Core 7:	7	17
Core 8:	8	18
Core 9:	9	19

#### CPU color codes

Tenant VM

OVS

vCIC

vFuel

Host OS