

Core 0:	0	14
Core 1:	1	15
Core 2:	2	16
Core 3:	3	17
Core 4:	4	18
Core 5:	5	19
Core 6:	6	20
Core 7:	7	21
Core 8:	8	22
Core 9:	9	23
Core 10:	10	24
Core 11:	11	25
Core 12:	12	26
Core 13:	13	27

CPU color codes

Tenant VM

OVS

vCIC

vFuel

Host OS