



# DRILLING TEMPLATE / QUICK GUIDE



## Cable connection guide

1. Connect the Sync cable, if applicable.
2. Connect the Fan cable, if applicable.
3. Connect the Ethernet cable, either to the RJ45 port or using an SFP plug.
4. Connect the DC-in cable if the Ethernet cable is connected to SFP.



<b>Tools</b> 	<b>Fasteners</b>  3x	<b>Safety Gear</b> 
<b>1</b> 	<b>2</b>  3x	<b>3</b> 
<b>4</b> 	<b>5</b>  3x	<b>6</b> 
<b>7</b> 	<b>8</b>  click	<b>9</b>  See cable connection guide
<b>10</b>  TX 20 1.5 Nm 2x	<b>11</b>  click	<b>12</b>  15 sec

**! ATTENTION**  
When conducting any installation or maintenance activities to the product, all cabling shall be disconnected first.