

EQUIPMENT TEST LIST
RHEOSTATS
MISCELLANEOUS APPARATUS

	CONTENTS	PAGE
11. GENERAL	1
11.0 RHEOSTATS	2
11.1 SW RHEO, POTS MN	2
11.2 STL PLT CARB PIL	2
11.3 MOTOR DRIVEN	2
11.4 BELL, BUZ, RIN & SOU	2
11.5 HEAD TEL SETS, & HEAD SETS	2
11. GENERAL		
11.01	This section provides an index and information access system to locate the standard tests applicable to equipment listed in	

the preceding table of contents. Test classification and frequency of periodic routine are also provided.

11.02 This is the first issuance of the "reformatted ETL" which provides better organization of the various tests. The "reformatted ETLs" replace the ETLs previously provided for this equipment.

11.03 Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

11.04 Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

11.05 Section 010-300-011 provides Equipment Test List instructions.

NOTICE
Not for use or disclosure outside the
Bell System except under written agreement

SECTION 028-001-012

11.0 RHEOSTATS

11.1 RHEOSTATS; SW RHEO,POTS MN

FOR ALL UNITS

028-720-701	(3/0)	2.02	LUBRICATION	MW 12M	-----
-------------	-------	------	-------------	--------	-------

11.2 RHEOSTATS; STL PLT CARB PIL

FOR ALL UNITS

028-721-701	(3/1)	2.09	LUBRICATION	MW 12M	-----
-------------	-------	------	-------------	--------	-------

		2.10	TIGHTNESS OF TERMINAL BAR CONNECTION	MW 12M	-----
--	--	------	--------------------------------------	--------	-------

11.3 RHEOSTATS; MOTOR DRIVEN

FOR ALL UNITS

028-722-701	(3/1)	2.02	(2.02 E2) LUBRICATE EXPOSED GEARS & CHAINS	MW 12M	-----
-------------	-------	------	--	--------	-------

		2.02	(2.02 E1) LUBRICATE BALL BEARING	MW 24M	-----
--	--	------	----------------------------------	--------	-------

		2.02	(2.02 C3) LUBRICATE LIMIT SWITCH ROLLER	MW M	-----
--	--	------	---	------	-------

		2.02	(2.02 C2) LUBRICATE WASTE PACKED BEARING	MW 6M	-----
--	--	------	--	-------	-------

		2.02	(2.02 C1) LUBRICATE SHAFT BEARINGS	MW M	-----
--	--	------	------------------------------------	------	-------

OPTIONAL FEATURES, SELECT NO MORE THAN ONE CATEGORY

GEAR BOX FOR RHEOSTATS KS-5349, KS-5385, KS-5445, & KS-5501

028-722-701	(3/1)	2.02	(2.02 D3) ADD OIL TO GEAR BOX WITHOUT OVERFLOW PLUG	MW 3M	-----
-------------	-------	------	---	-------	-------

		2.02	(2.02 D2) ADD OIL TO GEAR BOX W/OVERFLOW PLUG	MW 3M	-----
--	--	------	---	-------	-------

		2.02	(2.02 D1) CLEAN & REFILL GEAR BOX	MW 24M	-----
--	--	------	-----------------------------------	--------	-------

GEAR BOX FOR RHEOSTATS KS-5713, KS-15571, & KS-15743

028-722-701	(3/1)	2.02	(2.02 E3) CLEAN & REPACK GEAR BOX	MW 24M	-----
-------------	-------	------	-----------------------------------	--------	-------

TROUBLE TESTS

028-720-701	(3/0)	2.03	(2.03-2.09) PART 2	TT	-----
-------------	-------	------	--------------------	----	-------

028-721-701	(3/1)	2.03	(2.03-2.09 & 2.11-2.13) PART 2	TT	-----
-------------	-------	------	--------------------------------	----	-------

028-722-701	(3/1)	2.01	(2.01 & 2.03-2.15) PART 2	TT	-----
-------------	-------	------	---------------------------	----	-------

11.4 RHEOSTATS; BELL,BUZ,RIN&SOU

TROUBLE TESTS

BELLS & BUZZERS

028-100-701	(3/0)	2.01	(2.01-2.07) PART 2	TT	-----
-------------	-------	------	--------------------	----	-------

028-101-701	(1/0)	2.01	CLEANING	TT	-----
-------------	-------	------	----------	----	-------

		2.02	COVER FIT	TT	-----
--	--	------	-----------	----	-------

		2.03	CLEARANCE BETWEEN CLAPPER & SLOT IN COVER (10 & 11 TYPE BELLS ONLY)	TT	-----
--	--	------	---	----	-------

		2.04	ELECT REQTS	TT	-----
--	--	------	-------------	----	-------

028-102-701	(4/0)	2.01	(2.01-2.11) PART 2	TT	-----
-------------	-------	------	--------------------	----	-------

028-110-701	(1/0)	2.01	ARMATURE AIR GAP	TT	-----
-------------	-------	------	------------------	----	-------

		2.02	ARMATURE MOVEMENT	TT	-----
--	--	------	-------------------	----	-------

		2.03	OPERATION TEST	TT	-----
--	--	------	----------------	----	-------

		2.04	TIGHTNESS OF NUTS & SCREWS	TT	-----
--	--	------	----------------------------	----	-------

028-111-701	(2/0)	2.01	CLEANING	TT	-----
		2.02	GAP BETWEEN ARM & CURE	TT	-----
		2.03	ARMATURE MOVEMENT	TT	-----
		2.04	TIGHTNESS OF LOCKNUT	TT	-----
		2.05	OPERATION	TT	-----
028-112-701	(2/0)	2.01	CLEANING	TT	-----
		2.02	TIGHTNESS OF SCREWS OF LOCKNUTS	TT	-----
		2.03	ELECT REQTS	TT	-----
028-113-701	(6/0)	2.01	(2.01-2.09) REQTS	TT	-----
		3.01	(3.01-3.09) ADJUSTING PROCEDURES	TT	-----
028-120-701	(1/0)		REQTS & ADJ PROCED	TT	-----
RINGERS					
028-130-701	(4/0)		REQTS & ADJ PROCED	TT	-----
028-131-701	(1/0)		REQTS & ADJ PROCED	TT	-----
SOUNDERS					
028-140-701	(1/0)		REQTS & ADJ PROCED	TT	-----
028-141-701	(1/0)	2.01	(2.01-2.04) REQUIREMENTS	TT	-----
11.5 RHEOSTATS; DL HD STS&HDSTS					
TROUBLE TESTS					
DIALS					
028-300-501	(4/0)	1.03	(A) SPEED TEST	TT	-----
		1.03	(B) SPEED TEST	TT	-----
		1.03	(C) SPEED TEST	TT	-----
		1.03	(D) PULSING SPRIGS TEST	TT	-----
028-300-701	(10/0)	2.01	(2.01-2.13) REQTS	TT	-----
HEAD TEL SETS & HEADSETS					
028-350-501	(2/1)	3	VISUAL INSPECTION	TT	-----
		4	ELECT TESTS	TT	-----
028-351-501	(4/0)	2.01	VISUAL INSPECTION	TT	-----
		3	ELECT. TESTS	TT	-----
028-360-501	(7/0)	3	METHOD	TT	-----
028-361-501	(2/0)	3	VISUAL INSP & ELECT. TESTS	TT	-----
028-362-501	(2/0)	2.01	VISUAL INSPECTION	TT	-----
		3.01	ELECT TESTS	TT	-----
028-363-501	(3/0)	2.01	VISUAL INSPECTION	TT	-----
		3.01	ELECT TESTS	TT	-----
028-370-501	(3/0)	3	METHOD	TT	-----
028-371-501	(3/0)	2.01	VISUAL INSPECTION	TT	-----
		3.01	ELECT TEST	TT	-----