

**EQUIPMENT TEST LIST**

**MISCELLANEOUS METHODS**

**SEE SECTION 010-300-011 FOR EQUIPMENT TEST LIST INSTRUCTIONS**

EQUIPMENT TEST LIST						
B.S.P.	I S S	TEST OR REQT.	EQUIPMENT AND WORK DESCRIPTION	CLASS	FREQ.	JOB NO.
069-1			CABLING, WIRING, SKINNING, CONNECTING			
069-135-501	2		SOLDERLESS CONNECTORS	MW	*	
069-3			CLEANING, TREATING, & RECONDITIONING OF			
			APPARATUS & EQUIPMENT			
069-305-301	3		GENERAL CLEANING OF EQUIPMENT	MW	*	
& ADDENDUM	1					
069-306-801	8		DELETED. SEE 026-001-011.			
& ADDENDUM	1					
069-330-801	2		DELETED. SEE 026-001-011.			
069-331-801	1		204-TYPE SEL BANK CONTACTS & ASSOC	MW	*	
			WIPERS TELEGRAPH & TOLL EQUIPMENTS			
069-370-801	2		KS-13835 READERS AND KS-13882	MW	*	
			PERFORATORS			
		5.01	<i>Readers</i>	MW	100H	
		5.13	<i>Perforators</i>	MW	*	
069-379-801	3		SWITCHBOARD EQUIPMENT	MW	*	
069-5			CLNG, TREATING, & RECONDITIONING OF			
			APP & EQUIP—STEP-BY-STEP OFFICES			
069-501-801	13		197- & 198-TYPE SWITCHES & ASSOC	MW	#	
& ADDENDUM	2		BANKS, COMMUTATORS T WIPERS			
			#AN1 (TRUNK FINDER APPLICATIONS)	MW	12M	
			#XBT SW SYS (TRUNK FINDER	MW	12M	
			APPLICATIONS)			
			#SXS AMA & CAMA (TRUNK FINDER	MW	6M	
			APPLICATIONS)			
			#SXS TOUCH TONE (TRUNK FINDER	MW	3M	
			APPLICATIONS)			
			#ALL OTHER	MR	12M	
069-502-801	2		SWITCHES—PLUNGER-TYPE PRIMARY AND	MW	*	
& ADDENDUM	1		SECONDARY LINE SWITCHES & OUTTRUNK SWITCHES			
069-1			CABLING, WIRING, SKINNING, CONNECTING			
069-140-811	7		SOLDERED CONNECTIONS USING			
			SOLDERING COPPERS			
		15.01	<i>Test &amp; Inspection of Electric</i>	TT		
			<i>Soldering Coppers</i>			
069-3			CLNG, TREATING, & RECONDITIONING			
			OF APP & EQUIP.			

EQUIPMENT TEST LIST						
B.S.P.	I S S	TEST OR REQT.	EQUIPMENT AND WORK DESCRIPTION	CLASS	FREQ.	JOB NO.
069-306-801	8		DELETED. SEE 026-001-011.			
& ADDENDUM	1					
069-307-801	2		NORTH ELECTRIC MULTICONTACT RELAYS	TT		
069-310-803	8		RELAYS (WIRE-SPRING TYPE)	TT		
069-311-801	3		10-, 11-, 26-, 27-, & 32-TYPE BANKS	TT		
& ADDENDUM	1		ASSOCIATED WITH ROTARY SELECTORS			
069-315-801	2		HEAT COIL AND PROTECTOR SPRING	TT		
			CONTACTS			
069-321-801	2		STUD-TYPE ROTARY SWITCHES, ATTENUATORS, POTENTIOMETERS, & RHEOSTATS	TT		
069-360-801	5		5-, 12-, AND 14-TYPE REGISTERS	TT		
069-365-801	2		SLIDE WIRE APPARATUS	TT		
069-380-811	3		PLUGS CLEANING & POLISHING USING PORTABLE PLUG CLEANER	TT		
069-380-812	2		PLUGS CLEANING & POLISHING USING COTTON SLEEVING	TT		
069-380-813	2		CLEANING SWITCHBOARD PLUGS USING THE NO. 497A OR 497B TOOL	TT		
069-386-801	3		KEY AND JACK CONTACTS	TT		
& ADDENDUM	1					
069-387-801	2		CLEANING FLARES OF JACKS	TT		
069-388-801	2		OPERATORS TELEPHONE SET JACKS	TT		
069-5			CLNG, TREATING, & RECONDITIONING OF APP & EQPT—STEP-BY-STEP OFFICES			
069-503-801	5		CLNG EQPT FRAMES BY MEANS OF COMPRESSED AIR STEP-BY-STEP OFFICES	TT		
069-6			CLNG, TREATING, & RECONDITIONING OF APP & EQPT—PANEL OFFICES			
069-601-801	5		SEQUENCE SWITCHES & 157-TYPE INTERRUPTERS	TT		
069-603-801	7		CLNG EQPT FRAMES BY MEANS OF COMPRESSED AIR-PANEL OFFICES—LOCAL & TANDEM	TT		
069-605-801	4		PANEL MULTIPLE BANK TERMINALS ASSOC MULTIPLE BRUSHES & GUIDE COMBS	TT		
069-605-803	4		PANEL MULT BRUSHES & GUIDE COMBS & CLNG MULT BRUSHES & GUIDE COMBS	TT		

