



CODED TOOLS
NO. 450A TO 465A
DESCRIPTION

→ TOOL, 450A




Substitute disc.
Replaces substitute disc R-1648 detail 3.
For use on vertical drive shafts.

TOOL, 451A




Bank contact cleaner.
For use in cleaning plunger type line switch bank contacts.

TOOL, 452A




Bank contact separator.
For use in cleaning plunger type line switch banks.

TOOL, 453A




Swivel spanner wrench.
Replaces the Nos. 238 and 238B tools.
For use in replacing oil sight rings.

TOOL, 454A



Adapter.
For use in coupling $1/4''$ rubber tubing to the vacuum cleaner hose.


TOOL, 455A



Adapter.
For use in coupling $1/2''$ rubber tubing to the vacuum cleaner hose.

SECTION 074-122-101


TOOL, 456A



Adjuster.

For use on 200 and 206 type selectors and power driven rotary selectors.

TOOL, 458A




Indicator finger.

Replaces finger of bracket and finger, R-2166

For use with the No. 121A gauge on reciprocating bar type interrupters.

TOOL, 459A Manufacture Discontinued.

TOOL, 462A




Spring adjuster.

For use on split contact springs of A and B type sequence switches and 157 type interrupters.

TOOL, 463A
TOOL, 464A

P-247876 Screw for 463A Tool
P-247877 Screw for 464A Tool

Thumb Screw (In ordering this part, state whether pen is equipped with bushing (earlier type) or plate (later type) screw clamp)




Ruling pens.

Note: If the handle requires replacement return the tool to W.E.Co. for repair.

The 463A tool is for use in applying multiple marking paint to jack mounting strips containing 92 type jacks.

The 464A tool is for use in applying multiple marking paint to jack mounting strips containing 49 or 141 type jacks.

TOOL, 465A



Stirring rod.

For use in stirring paint and filling the Nos. 463A and 464A tools with paint in multiple marking work.