

TOOLS

BRIDGES – DESCRIPTION


1. GENERAL

- 1.01 This section covers coded Bell System bridge tools.
- 1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03 The information contained in this section supersedes the corresponding information in Section 074-140-101.

Order this tool for replacement purposes only if the office is equipped with the 1012A tool kit. The 1012A tool kit is no longer available as a complete kit.
For use with 666A, 667A, and 668A tools in replacing core plates and coils of 287- and 288-type relays.


665A

A&M ONLY



665B

A&M ONLY



Order this tool for replacement purposes only if the office is equipped with the 1012A tool kit. The 1012A tool kit is no longer available as a complete kit.
For use with 666A, 667A, and 668A tools in replacing core plates and coils of 286-type relays.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement