

TOOLS

CLEANERS III - DESCRIPTION

1. GENERAL

- 1.01** This section covers noncoded Bell System cleaner tools.
- 1.02** When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03** The information contained in this section supersedes the corresponding information in Sections 074-580-101, 074-755-101, and 074-800-101.
- 1.04** See tool index for other Cleaner practices. Also see Brushes, Section 074-205-138.

CLEANER, VACUUM, KS-14410 L2

(Includes L11 hose, L20 adapter and L22 filter cones. Order other attachments by list number given.)




Portable upright tank-type vacuum cleaner for use where heavy duty or silent type, such as KS-14377, is not required. It is approximately 11 inches in diameter and 13 inches high, exclusive of handle. Weight, without attachments, is approximately 17 pounds. It may be mounted on a rolling ladder by using a 32B ladder bracket. It is equipped with a three-wire 19-foot long KS-14410 L31 power cord. For general use.

When ordering hose, cleaning attachments, carriage, or adapters, use the following wording. Attachments L12 to L19 inclusive may be ordered as a set by specifying L30.

Adapter, KS-14410 L20
Adapter, KS-14410 L21
Attachments, Set, KS-14410 L30
Brush, Round, KS-14410 L19
Brush, Upholstery, KS-14410 L17
Carrige, KS-14410 L10
Cone, Filter, KS-14410 L22 (See Note)
Hose, Suction, KS-14410 L11
Nozzle and Brush, Floor, KS-14410 L14
Nozzle, Crevice, KS-14410 L18
Nozzle, Upholstery, KS-14410 L16
Polisher, Floor, KS-14410 L15
Tube, Extension, Lower, KS-14410 L12
Tube, Extension, Upper, KS-14410 L13

Note: L22 provides one dozen filter cones.



KS-14410 L10 Carriage



KS-14410 L11 (7-3/4') Hose

NOTICE


Not for use or disclosure outside the
Bell System except under written agreement

CLEANER, VACUUM, KS-14410 L2 (CONT)


The L11 hose may also be used with Filter Queen model 500 or 200 vacuum cleaner. If it is desired to use KS-14410 L12, L13, L14, L16, or L20 attachments with model 200 cleaner, hose furnished with that cleaner must be replaced by L11 hose.



KS-14410 L12 Lower Extension Tube



KS-14410 L13 Upper Extension Tube



KS-14410 L14 Floor Nozzle and Brush



KS-14410 L15 Floor Polisher

The L15 floor polisher fits the L14 floor nozzle and brush.




KS-14410 L16
(6'') Upholstery
Nozzle



KS-14410 L17
(6'') Upholstery
Brush

The L17 brush fits the L16 nozzle.



KS-14410 L18
Crevice Nozzle



KS-14410 L19
Round Brush



KS-14410 L20 Adapter

The L20 adapter permits use of the 454A and 455A tools, the KS-2629 and KS-2852 attachments, and other attachments having similar hose connection openings with the KS-14410 L11 hose.


The L20 adapter cannot be used with the hose for the Filter Queen model 200 vacuum cleaner. See KS-14410 L11 hose.




KS-14410 L21 Adapter

The L21 adapter permits use of KS-14410 attachments with KS-14377 L11 and L12 hoses.

ATTACHMENT, CLEANER, VACUUM, KS-2629



Consists of a fiber tube nozzle and a 3-foot long flexible hose. Furnished with one KS-3093 brush. For use on 153-type interrupters.

NOZZLE, CLEANER, VACUUM, KS-2852

For use on 153-type interrupters.

NOZZLE, CREVICE, CLEANER, VACUUM, R-2379, DET. 1

Replaced by crevice nozzle KS-14377 L14. For use on panel multiple banks.

NOZZLE, CREVICE, CLEANER, VACUUM, MORRILL AND MORRILL NO. 14

Replaced by crevice nozzle KS-14377 L13. For use on panel multiple banks.

TOOL, CLEANER, VACUUM, B. F. STURTEVANT CO.


Replaced by nozzle KS-14377 L15. For use on sequence switches and 157-type interrupters.

EXHAUSTER, KS-14426 L5

For use in collecting airborne dust when cleaning central office apparatus with compressed air. See Section 074-214-125.

GUN, HOT AIR, KS-14586

For use in removing contact protectant from panel bank guide combs and multiple brush rollers. See Section 074-220-142.

SCRUBBER, CAM, KS-14654 L1

Mounts three KS-14686 pads which are arranged to scrub six cam sides simultaneously. The pads must be ordered separately. Refer to Section 069-601-801 for piece-part data and maintenance information for this tool. Replaces the 435A tool. For use in cleaning cams of sequence switches and 157-type interrupters.

FLUSHING UNITS, KS-16297 L50 AND KS-16916 L1

For use in cleaning step-by-step banks. See Section 074-217-124.

GRIP, HAND 469A

For use in cleaning rotor hubs. See Section 074-220-132.


HANDLE, KS-16298

For use in cleaning step-by-step bank contacts and separators. See Section 074-223-108.

HANDLE, KS-16884 L1

MFR DISC

SCRUBBERS, KS-16914 L1 AND KS-16915 L1




SCRUBBERS	DIM. "A"	ASSOC. RIBBON	RIBBON LENGTH	PACKAGE
KS-16914 L1	4.5"	KS-16928 L1	12"	50
KS-16915 L1	3"	KS-16928 L2	9"	50

The KS-16928 L1 and L2 ribbons used with this tool must be ordered separately.

KS-16914 L1 is used in cleaning sleeve terminals of the panel selector banks.

KS-16915 L1 is used in cleaning sleeve and hunt terminals of panel line finder banks.

TOOL, PRESSURE, D-156695



For use in cleaning plunger-type line switch springs.