

CLEANERS III

DESCRIPTION

TOOLS

CONTENTS

PAGE

1. GENERAL	1
2. DESCRIPTION OF TOOLS	1

1. GENERAL

1.01 This section describes Bell System coded, noncoded, and commercial cleaner tools within the part or type number range of D-156695 through R-2379 and KS-2629 through KS-16915.

1.02 Revision arrows are used to emphasize significant changes. The reasons for reissuing this section are listed below:

- (a) To reinstate the R-2379 crevice nozzle
- (b) To rate the KS-2629 and KS-2852 hose-nozzle assemblies Mfr Disc.
- (c) To rate the KS-14654, L1, cam scrubber Mfr Disc.
- (d) To rate the KS-16914, L1, and KS-16915, L1, scrubbers Mfr Disc.
- (e) To add a Table A to include Mfr Disc. tools and their replacements
- (f) To revise Table B.

1.03 See tool index, Section 074-000-001, for other Cleaner practices. Also see Brushes, Section 074-205-138.

1.04 Table A lists cleaner tools which are Mfr Disc. with their replacements.

2. DESCRIPTION OF TOOLS

2.01 ♦**R-2379**: The R-2379 crevice nozzle and bend consist of a standard No. 14 Protos crev-

ice nozzle and a No. 7A bend, for use with vacuum cleaners.♦

2.02 **KS-14410, L2**: The KS-14410, L2, (Fig. 1) is a portable upright tank-type vacuum cleaner for use where a heavy duty or silent type vacuum cleaner is needed. It is approximately 11 inches in diameter and 13 inches high, exclusive of handle. Weight, without attachments, is approximately 17 pounds. It may be mounted on a rolling ladder by using a 32B ladder bracket. This cleaner is equipped with a 3-wire, 19-foot long KS-14410, L31, power cord. This cleaner is for general use and includes L11 hose, L20 adapter, and L22 filter cones. Order other attachments by list number given in Table B. When ordering hose, cleaning attachments, carriage, or adapters, use the wording provided in Table B. Attachments L12 to L19 inclusive may be ordered as a set by specifying L30. The KS-14410, L2, vacuum cleaner replaces the KS-14377 vacuum cleaner.



Fig. 1—KS-14410, L2, Vacuum Cleaner

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

♦TABLE A♦

CLEANER TOOLS III — MFR DISC.

PART NO.	DESCRIPTION	REPLACEMENT
D-156695	Pressure Tool	—
KS-2629	Hose Nozzle Assembly	—
KS-2852	Vacuum Cleaner Nozzle	—
KS-14410, L1	Vacuum Cleaner	KS-14410, L2
KS-14654, L1	Cam Scrubber	—
KS-16914, L1	Scrubber	—
KS-16915, L1	Scrubber	—
B. F. Sturtevant Co	Vacuum Cleaner Nozzle	KS-14410, L18
Morrill and Morrill, No. 14	Vacuum Cleaner Crevice Nozzle	KS-14410, L18

♦TABLE B♦

KS-14410 ATTACHMENTS

LIST NO.	ATTACHMENT	FIG. NO.
10	Carriage Assembly	2
11	Suction Hose (7.75 feet)	3
12	Lower Extension Tube	4
13	Upper Extension Tube	5
14	Floor Nozzle and Brush	6
15*	Floor Polisher	7
16	Upholstery Nozzle	8
17†	Upholstery Brush	9
18	Crevice Nozzle	10
19	Round Brush	11
20‡	Adapter	12
21§	Adapter Assembly	13
22¶	Filter Cone	—
30**	Attachment Set	14

* The L15 floor polisher fits the L14 floor nozzle and brush.

† The L17 upholstery brush fits the L16 upholstery nozzle.

‡ The L20 adapter permits use of the 454A and 455A tools, the KS-2629 attachment, and other attachments having similar hose connection openings with the KS-14410, L11, hose. The L20 adapter cannot be used with the hose for the Filter Queen model 200 vacuum cleaner.

§ The L21 adapter assembly permits use of KS-14410 attachments with KS-14377, L11, and L12, hoses.

¶ The L22 filter cone is provided in packages of one dozen filters.

** The L30 attachment set includes items KS-14410, L12 through L19, inclusive.




Fig. 2—KS-14410, L10, Carriage Assembly



Fig. 3—KS-14410, L11, Suction Hose (7.75 Feet)




Fig. 4—KS-14410, L12, Lower Extension Tube




Fig. 5—KS-14410, L13, Upper Extension Tube




Fig. 6—KS-14410, L14, Floor Nozzle and Brush




Fig. 10—KS-14410, L18, Crevice Nozzle



Fig. 7—KS-14410, L15, Floor Polisher



Fig. 11—KS-14410, L19, Round Brush



Fig. 8—KS-14410, L16, Upholstery Nozzle




Fig. 12—KS-14410, L20, Adapter




Fig. 9—KS-14410, L17, Upholstery Brush





Fig. 13—KS-14410, L21, Adapter Assembly



KS-14410 L12 LOWER EXTENSION TUBE



KS-14410 L13 UPPER EXTENSION TUBE



KS-14410 L14 FLOOR NOZZLE AND BRUSH




KS-14410 L15 FLOOR POLISHER



KS-14410 L16 (6'') UPHOLSTERY NOZZLE



KS-14410 L17 (6'') UPHOLSTERY BRUSH



KS-14410 L18 CREVICE NOZZLE



KS-14410 L19 ROUND BRUSH

Fig. 14—KS-14410, L30, Attachment Set