

TOOLS

CUTTERS - DESCRIPTION


1. GENERAL

- 1.01 This section covers coded and noncoded Bell System cutter tools.
- 1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03 The information contained in this section supersedes the corresponding information in Sections 074-108-101, 074-132-101, and 074-595-101.

312 CORD CUTTER

MFR DISC


312B



Cord cutter. The base is provided with screw holes for attaching to the KS-5263 cord repair table. For use in repairing switchboard cords by the solderless cord-tip method.

313

A&M ONLY




Conductor braid cutter. For use in repairing switchboard cords by the punched-hole method. The information covered herein replaces the part of Section 074-000-006, Issue 1, applying to this tool.

590A OIL CLOSURE CUTTER

MFR DISC

CUTTER, TAB, KS-21030 L1




Used to remove the hairpin select wire tab prior to select wire replacement within vertical units of a small crossbar switch.

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

CUTTER, STRAP, R-2528



For cutting slots in straps to separate groups, when required, on 15-type banks.