

TOOLS

EXTRACTORS II - DESCRIPTION

1. GENERAL

- 1.01 This section covers coded and noncoded Bell System extractors.
- 1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03 The information contained in this section supersedes the corresponding information in Sections 074-153-101 and 074-605-101.
- 1.04 See tool index for another Extractor practice.
- 1.05 For similar types of tools, see Pullers, Section 074-247-137; Removers I, Section 074-253-123; and Removers II, Section 074-253-124.

Extractor tool. For use in extracting or inserting plug-in units in the No. 4A and 4M Toll Switching Systems.


793A

See Section 074-226-119.


811A

Circuit pack extractor. Used to extract number network printed wiring boards from ANI-D number network apparatus mountings.

KS-5637 L1



758A



Tube extractor. For use in extracting 373A and 374A electron tubes from K2 carrier telephone equipment panels.


KS-13753 L1

MFR DISC

Tube extractor. Replaced by the KS-13753 L2 extractor.

Extractor tool. For use in removing printed wiring boards from the tray in the No. 5 Crossbar System. Handle is epoxy coated.


761A



NOTICE


Not for use or disclosure outside the Bell System except under written agreement

KS-13753 L2




Tube extractor. Replaces the KS-13753 L1 extractor. For use in extracting 7-pin and 9-pin miniature electron tubes.

KS-14408




Tube extractor. For use in extracting and inserting the 416A electron tubes.

KS-14428




Tube extractor. For use in extracting the 375A and similar-type octal base electron tubes and for removing and replacing 89-type resistors.

KS-14457




Pin extractor. For use in removing and replacing pins in KS-13882 perforators in AMA accounting centers and central offices.

KS-19099 L1




For use in removing packaged semiconductor amplifiers from L-type multiplex equipment.

KS-19898 L1




For use in removing the 372A and similar-type patching plugs from the A2A Video System.

KS-20141 L1




For use in extraction and insertion of 51A pads in L4 Coaxial System.

KS-21144 L1



Lamp and cap extractor. A double-ended tool used to remove the cap and T1-type lamp from the miniature lamp assemblies used in L4 and L5 terminal equipment. Refer to Section 075-126-301 for details and use.


EXTRACTOR, MORRILL AND MORRILL NO. 218



For use in extracting 310- and 311-type electron tubes.

EXTRACTOR, HELI-COIL CORP


In ordering, specify number of tool desired.



TOOL NUMBER	WILL EXTRACT "INSERTS"	THREAD SIZES
1227-06	1185-2CN	8-32
1227-6	1191-3CN	10-32
1227-6	1191-4CN	1/4-28
1227-6	1191-5CN	5/16-24

For use on KS-13835 readers.

EXTRACTOR, TUBE, GENERAL CEMENT MFG COMPANY NO. 5092



Replaces the Insuline Corp No. 1001 tube extractor. For use in extracting and inserting miniature electron tubes which have deeply recessed sockets or sockets with base-shield extensions.

EXTRACTOR, TUBE, INSULINE CORP NO. 1001

Replaced by the General Cement Mfg Company, No. 5092 tube extractor.