

## TOOLS

### FLUSHING—DESCRIPTION

#### 1. GENERAL

KS-16297 L50

1.01 This section covers noncoded Bell System flushing tools.


1.02 This section is reissued to add the KS-16297 L70 flushing unit. Since this reissue is a general revision, no revision arrows have been used to denote significant changes. The Equipment Test List is not affected.

1.03 The information contained in this section supersedes the corresponding information in Section 074-840-101.

1.04 See tool index for other Cleaner practices.

#### KS-16297 L1—Manufacture Discontinued

Flushing. Replaced by KS-16297 L50 flushing unit.




Flushing. Refer to Section 069-501-801 for replacement parts and other maintenance information on the flushing unit. For use in cleaning step-by-step banks.

#### NOTICE


Not for use or disclosure outside the  
Bell System except under written agreement

KS-16297 L70



Flushing. Refer to Section 069-501-801 for replacement parts and other maintenance information on the flushing unit. For use in cleaning step-by-step banks.

KS-16916 L1



Flushing. Refer to Section 069-605-803 for replacement parts and other maintenance information on the flushing unit. For use in cleaning panel bank sleeve and hunt terminals.