

TOOLS

MOUNTING - DESCRIPTION


1. GENERAL

1.01 This section covers coded Bell System mounting tools.

1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.


1.03 The information contained in this section supersedes the corresponding information in Sections 074-139-101 and 074-141-101.

664A



Operating spring stud cap mounting tool. For use in removing and replacing operating spring stud caps on worn studs of 245-, 254-, 263-, and 264-type relays.

677A



Commutator brush guide mounting tool. For use in installing rear guides on panel commutator brushes.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement