

## TOOLS

### MOUNTING—DESCRIPTION

#### 1. GENERAL


1.01 This section covers coded Bell System mounting tools.

1.02 This section is reissued to add the 852A tool. The Equipment Test List is not affected.

1.03 The information contained in this section supersedes the corresponding information in Sections 074-139-101 and 074-141-101.


#### 2. DESCRIPTION OF TOOLS

##### 664A




Operating spring stud cap mounting tool. For use in removing and replacing operating spring stud caps on worn studs of 245-, 254-, 263-, and 264-type relays.

##### 677A



Commutator brush guide mounting tool. For use in installing rear guides on panel commutator brushes.

##### 852A



Used for attaching individual wires to the 711 connector mandrel.

#### NOTICE

Not for use or disclosure outside the  
Bell System except under written agreement