


TOOLS
RELEASERS – DESCRIPTION

1. GENERAL


- 1.01 This section covers coded and noncoded Bell System releasers.
- 1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03 The information contained in this section supersedes the corresponding information in Sections 074-127-101 and 074-750-101.

522A



Partition releaser. For use in removing partitions from information desk book racks.

KS-21107



Consists of a brass, double-ended, pen-type combination tool containing three retractable bits at one end and a wedge-shaped extension at the other end.

The L20 bit is used to remove number card covers. The L30 bit is used to adjust the rate totalizer in single-slot coin telephones and to remove finger wheels from standard dials. The L40 bit is used to remove finger wheels from the 8A- and 8U-type dials. The wedge is used to remove TRIMLINE® telephone cord plugs.

Replaces the KS-16750 L4 releaser.

NOTICE

Not for use or disclosure outside the Bell System except under written agreement