


TOOLS
REPLACERS – DESCRIPTION

1. GENERAL

- 1.01 This section covers coded Bell System replacers.
- 1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.
- 1.03 The information contained in this section supersedes the corresponding information in Sections 074-125-101 and 074-140-101.
- 1.04 For similar types of tools, see Removers I, Section 074-253-123.


495A



Pawl pin replacer. Forms part of the 1001A tool kit. For use in replacing pawl pins on 197- and 198-type switches.


666A

A&M ONLY



Core plate replacer. Order this tool for replacement purposes only if the office is equipped with the 1012A tool kit. The 1012A tool kit is no longer available as a complete kit. For use in replacing core plates of 286-, 287-, and 288-type relays.

666B



Core plate replacer. Replaces the 716C tool. Forms a part of the 1014B tool kit. For use in replacing core plates of 286-, 287-, and 288-type relays.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement