

**NONCODED TOOLS**  
**VACUUM CLEANERS AND ATTACHMENTS**  
**DESCRIPTION**

---

**CLEANER, VACUUM, KS-8389**

Replaced by Vacuum Cleaner, KS-14377 L1 and L2, and KS-14410 L1

---

**CLEANER, VACUUM, KS-14377 L1 and L2**

Replace by Vacuum Cleaners, L3 and L4

---

**CLEANER, VACUUM, KS-14377 L3 and L4 "Mfr. Disc."**

Replaced by KS-14377 L5 and L6

---

**CLEANER, VACUUM, KS-14377 L5 and L6**

(Order hose and attachments desired by list numbers given below:)



Heavy duty portable upright tank-type vacuum cleaners. L5 cleaner is standard type cleaner, designed to use paper filters. L6 cleaner is similar to L5 except for motor refinements which result in quieter operation. It is recommended for locations where noise must be kept to minimum. Pamphlet 6013 supplied with Conversion Kit L25 gives information for converting L1 and L2 cleaners for use with paper filters. The cleaners are approximately 10 in. in diameter, 18-1/2 in. high, exclusive of handle, and weigh without attachments approximately 23 lbs. May be mounted on a rolling ladder by using 32B ladder bracket.

Equipped with a 3-wire 25-foot long KS-14377 L31 power cord.

For piece-part and replacement data, see Section 075-180-803.

For requirements and adjustments, see Section 075-180-703.

For general use.

Hose, attachments, carriage and carton of paper filters must be ordered separately in accordance with ordering information below. Attachment end of KS-14377 L11 and L12 hose accommodates standard tools and fittings used with former cleaners, including 454A and 455A tools and KS-2629 and KS-2852 attachments. When hose is equipped with KS-14410 L21 adapter, KS-14410 L12 to L20 attachments, inclusive, may also be used. KS-14377 attachments are for general use except for L14 and L15 which have special uses stated under illustration.

When ordering hose, cleaning attachments, or carriage, use wording below:

Assembly, Filter, KS-14377 L26 (not illustrated) includes:

Filter, Cambric, Felt, KS-14377 L27 (not illustrated)

Gasket, Rubber, KS-14377 L28

Ring, Aluminum, KS-14377 L29

Brush, Detachable, KS-14377 L22

Brush and Holder, Radiator, KS-14377 L17

Brush and Holder, Round, KS-14377 L23

Brush, Swivel, KS-14377 L16

Carriage, KS-14377 L

Carton of Paper Filters, KS-14377 L24 (not illustrated)

Hose, KS-14377 L11

Hose, KS-14377 L12

Kit, Conversion, KS-14377 L25 (for converting L1 and L2 to L3 and L4) (not illustrated)

Nozzle, KS-14377 L15

Nozzle, Crevice, KS-14377 L13

Nozzle, Crevice, KS-14377 L14


Nozzle, Floor, Swivel, KS-14377 L20

Nozzle, Rubber, Flexible, KS-14377 L30

Nozzle, Upholstery, KS-14377 L21

Tube, Fiber, KS-14377 L18


Tube, Fiber, Curved, KS-14377 L19



KS-14377 L10 Carriage



KS-14377 L11 (8-foot) Hose



KS-14377 L12 (Extensible) Hose

The L12 hose is extensible from about 4 feet long collapsed to about 10 feet long extended.




KS-14377 L13  
Crevice Nozzle



KS-14377 L14  
Crevice Nozzle

The L14 crevice nozzle is for use on panel multiple banks.



KS-14377 L15  
Nozzle



KS-14377 L16  
(5") Swivel Brush

The L15 nozzle is for use on sequence switches and 157-type interrupters.



KS-14377 L17 Radiator Brush and Holder


Replaceable brush may be ordered separately as "filler for KS-14377 L17 Radiator Brush and Holder".



KS-14377 L18 (36-ounce) Fiber Tube



KS-14377 L19 Curved Fiber Tube



KS-14377 L20 (12") Swivel Floor Nozzle




KS-14377 L21  
(5") Upholstery  
Nozzle



KS-14377 L22  
(6") Detachable  
Brush

The L22 brush fits the L21 nozzle.



KS-14377 L23 Round Brush and Holder

Replaceable brush may be ordered separately as "filler for KS-14377 L23 Round Brush and Holder".



KS-14377 L28 Rubber Gasket



KS-14377 L29 Aluminum Ring




KS-14377 L30 Flexible Rubber Nozzle

**CLEANER, VACUUM, KS-14410 L1** "Mfr Disc."  
Replaced by Vacuum Cleaner, KS-14410 L2

**CLEANER, VACUUM, KS-14410 L2**

(Includes L11 hose, L20 adapter and L22 filter cones. Order other attachments by list number given below:)




Portable upright tank-type vacuum cleaner for use where heavy duty or silent type, such as KS-14377, is not required. It is approximately 11 inches in diameter and 13 inches high, exclusive of handle. Weight, without attachments, is approximately 17 lbs. It may be mounted on a rolling ladder by using a 32B ladder bracket. It is equipped with a 3-wire 19-foot long KS-14410 L31 power cord.

For general use.

When ordering hose, cleaning attachments, carriage, or adapters, use wording given below. Attachments, L12 to L19 inclusive, may be ordered as a set by specifying L30.

Adapter, KS-14410 L20  
Adapter, KS-14410 L21  
Attachments, Set, KS-14410 L30  
Brush, Round, KS-14410 L19  
Brush, Upholstery, KS-14410 L17  
Carriage, KS-14410 L10  
Cone, Filter, KS-14410 L22 (See Note 1)  
Hose, Suction, KS-14410 L11  
Nozzle and Brush, Floor, KS-14410 L14  
Nozzle, Crevice, KS-14410 L18  
Nozzle, Upholstery, KS-14410 L16  
Polisher, Floor, KS-14410 L15  
Tube, Extension, Lower, KS-14410 L12  
Tube, Extension, Upper, KS-14410 L13

**Note 1:** L22 provides 1 dozen filter cones.




KS-14410 L10 Carriage




KS-14410 L11 (7 3/4') Hose


The L11 hose may also be used with Filter Queen model 500 or 200 vacuum cleaner. If it is desired to use KS-14410 L12, L13, L14, L16, or L20 attachments with model 200 cleaner, hose furnished with that cleaner must be replaced by L11 hose.



KS-14410 L12 Lower Extension Tube



KS-14410 L13 Upper Extension Tube



KS-14410 L14 Floor Nozzle and Brush



KS-14410 L15 Floor Polisher

The L15 floor polisher fits the L14 floor nozzle and brush.



KS-14410 L16 (6') Upholstery Nozzle



KS-14410 L17 (6') Upholstery Brush

The L17 brush fits the L16 nozzle.



KS-14410 L18 Crevice Nozzle



KS-14410 L19 Round Brush



KS-14410 L20 Adapter


The L20 adapter permits use of the 454A and 455A tools, the KS-2629, and KS-2852 attachments and other attachments having similar hose connection openings, with the KS-14410 L11 hose.

The L20 adapter can not be used with the hose for the Filter Queen model 200 vacuum cleaner. See KS-14410 L11 hose.




KS-14410 L21 Adapter

The L21 adapter permits use of KS-14410 attachments with KS-14377 L11 and L12 hoses.

**ATTACHMENT, CLEANER, VACUUM, KS-2629**

Consists of a fiber tube nozzle and a 3 foot long flexible hose. Furnished with one KS-3093 brush.

For use on 153-type interrupters.

**NOZZLE, CLEANER, VACUUM, KS-2852**

For use on 153-type interrupters.

**NOZZLE, CREVICE, CLEANER, VACUUM, R-2379, Det. 1**

Replaced by crevice nozzle KS-14377 L14.  
For use on panel multiple banks.

**NOZZLE, CREVICE, CLEANER, VACUUM, MORRILL AND MORRILL NO. 14**

Replaced by crevice nozzle KS-14377 L13.  
For use on panel multiple banks

**TOOL, CLEANER, VACUUM, B. F. STURTEVANT CO.**

Replaced by nozzle KS-14377 L15.  
For use on sequence switches and 157-type interrupters.