


NONCODED TOOLS

RACKS, READERS, REAMERS, RECEIVERS, REELS, AND RELEASERS


DESCRIPTION

RACK, KS-16498 L1



For use in handling the 214A selector of 1-type translators


READER, TAPE KS-14343



Perforated metal plate.

For use in visually translating coded perforations in AMA tape.


REAMER, D-87464, 0.313"



Supplied complete with handle unless otherwise specified in the order.


For use on 5- and 6-type distributor.

REAMER AND HANDLE, D-97083, 0.624"



For use with the D-97084 tapered bushing in reaming bearings in worm case housings of friction roll drives to relieve overheating.

REAMER AND HANDLE, D-97085, 3/8"




For use with the D-97086 guide and clamp nut, for reaming housing assembly bearings of friction roll drives to relieve overheating.

RECEIVER AND CORDS, TESTER'S, R-9572


Replaced by headset composed of one 716C receiver, one 11A headband and one 2W21A cord.

REEL, WIRE, KS-8047



For use in central offices for holding distribut-ing frame wire.

REEL, WIRE, KS-8289




For use in central offices for holding distributing frame wire.

RELEASER, KS-16750 L1 "Mfr Disc."
Replaced by KS-16750 L2 Releaser.

RELEASER, KS-16750 L2 "Mfr Disc."
Replaced by the KS-16750 L3 Releaser

RELEASER, KS-16750 L3



Consists of a metal pin mounted in a cast resin handle and a removable cap.

For use in releasing the plastic finger wheel from No. 6 and No. 7 type dials and for releasing cord plug from Trimline® handset.