

B WIRE LOOP

1. GENERAL

1.01 The B wire loop (Fig. 1), together with the D masonry fastener, is used as an intermediate support of station wires and inside wiring cable attached to masonry surfaces.




Fig. 1 — B-Wire Loop

1.02 Table A lists size number, width, and length of B wire loop.

TABLE A

Size No.	Width of Opening (W)	Length of Loop (inside) (L)
	In.	
1/2	1/4	3/4
5/8	1/2	1-1/8
7/8	5/8	2-1/16
1-1/4	5/8	2-3/4

1.03 D masonry fasteners are used to attach B wire loops. Table B contains the recommended D masonry fastener used on various masonry surfaces.

TABLE B

Loops	Mounting Surface	D Masonry Fastener Size No.
1/2, 5/8, 7/8, 1-1/4	Concrete	3
	Mortar	4
	Cement or Cinder Block	5