

INSIDE WIRING CABLE CLAMPS

1. GENERAL

1.01 Inside wiring cable clamps (Fig. 1) are used to support inside wiring cables and station wires.




Fig. 1 – Inside Wiring Cable Clamps

1.02 Cable clamps are secured by means of a fastener placed through a centrally located mounting hole. The recommended fastener for securing cable clamps to various surfaces is covered in Plant Series Section 461-200-210.

1.03 Table A contains clamp size, finish, wire capacity, and diameter of mounting hole.

TABLE A

Size No.	Finish	Diameter of Mounting Hole	For Cable Capacity
		(in.)	(pr)
3	Ivory or Light olive gray	5/32	For Station Wire
5	Ivory or Light olive gray	5/32	6-16
6	Light olive gray	7/32	21-25
8	Light olive gray	7/32	50
10	Light olive gray	7/32	75
12	Light olive gray	7/32	100