

ALPHABETICAL INDEX
GAUGES

DESCRIPTION	CODE	SECTION
A		
AECo Specifications		
Block, Gauge, Line Switch Plunger	H-7541-3	084-510-101
Alignment Gauge, Vertical		
Drive Shaft	R-5320	084-540-101
Ammeters, Weston		
Ranges		
Amperes (AC) 1, 3, 5, 10, 50	Model 155	084-501-101
Amperes (AC) 1, 3, 5, 10, 50	Model 528	084-501-101
Amperes (DC) 0.60 and 1.8	Model 1	084-505-101
Amperes (DC) 1.5, 3, 30, 100	Model 281	084-505-101
Amperes (DC) 150 and 1500	Model 901	084-505-101
Ammeters, AC-DC, Clamp-On		
Columbia Electric		
Type CS, 75, 200 and 500 Ampere Scale Ranges		084-501-101
Type P, 20 Ampere Scale Range		084-501-101
Ammeters	KS-19516,L1	084-501-101
	KS-19516,L2	084-501-101
	KS-19516,L4	084-501-101
	KS-19516,L5	084-501-101
	KS-19516,L6	084-501-101
Ammeters	KS-19563,L1	084-505-101
	KS-19563,L2	084-505-101
	KS-19563,L3	084-505-101
	KS-19563,L4	084-505-101
See also Microammeter, Milliammeters, Volt-Ammeter, Volt-Milliammeter, and Volt-Ohm-Milliammeter.		
Anemometer, 4 inches		084-510-101
Armature Locating Gauges	149B	084-120-101
	162B	084-122-101
Armature Overlap Gauge	160A	084-120-101
AT&TCo Specification		
Thermometer, Line	AT-6639N	084-750-101
Rule, Measuring, 6-Foot	AT-6911	084-645-101

NOTICE

Not for use or disclosure outside the
 Bell System except under written agreement

SECTION 084-000-001

DESCRIPTION CODE SECTION

B

Balances		
Spring, 0 to 3 Lbs.....	R-2202	084-510-101
Spring, 0 to 6 Lbs.....	R-2771	084-510-101
Spring, 0 to 30 Lbs.....	R-2481	084-510-101
Block, Gauge, Line Switch		
Plunger, AEC0	H-7541-3	084-510-101
Break Meter, Percent	KS-7361	084-640-101
Brush Rod Gauge	108A	084-111-101
Butt Test Plugs; See Jack Gauges.		

C

Calibrating Plug For 197A Plug	198A	084-128-101
Calipers		
Inside, 8 inches		084-510-101
Outside, 4 inches		084-510-101
Outside, 8 inches		084-510-101
Outside Micrometer, Brown and Sharpe	54RS	084-510-101
Cam Locating Gauge, Off-Normal	143A	084-117-101
Coin Relay	147A	084-117-101
Cord Weight, See Weights.		
Counter, Impulse	KS-7608	084-510-101
Cross Test Plugs, See Jack Gauges.		
Cutout Test Plugs, See Jack Gauges.		

D

Dial Indicator Gauges		
Panel Clutches	121A	084-113-101
Vertical Drive Shafts	R-2040	084-540-101
Drive Shaft Alignment Gauge, Vertical	R-5320	084-540-101

F

Fan Type Gauges, See Gram		
Gauge, Fan Type.		
Fixtures, Shaft Locating	120A	084-113-101
Frequency Meter, See Meter, Frequency.		

DESCRIPTION	CODE	SECTION
G		
Galvanometer, Weston	Model 375	084-510-101
Gap, Screw	150B	084-120-101
Gauge Block, Line Switch Plunger, AECo	H-7541-3	084-510-101
Gauge, U.S. Gauge Co 2-1/2 Inch Range 0-15 Inches of Water	6336	084-540-101
Gauge Height, Step-by-Step	KS-20606	084-540-101
Non-Trapping CA-CF Small Crossbar Switches	KS-20650	084-545-101
Gram Gauges, Fan-Type		
0-30	70H	084-103-101
0-700	62B	084-103-101
0-150	70J	084-103-101
0-1400	158A	084-120-101
10-0-10	70F	084-103-101
50-0-50	70D and G	084-103-101
70-0-70	68B, C and D	084-103-101
Gram Weights		
50, 50, 50, 100, 150, and 1300	93B	084-109-101
10, 25, 50, 100, and 500	KS-6338	084-870-101

H

Hydrometers		
Electric Storage Battery Company Floating		084-550-101
Syringe	KS-5499	084-550-101

I

Impulse Counter	KS-7608	084-510-101
Indicator Gauges, Dial, See Dial Indicator Gauges.		
Indicator, Speed, See Tachometers.		
Indicator, Test, Universal Type		084-600-101
Inside Micrometer, Brown and Sharpe	263	084-640-101
Interrupter, Locating Gauge	76	084-105-101

J

Jack, Gauges		
49- and 141-Type Jacks		

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
Butt Test Plug	124B	084-113-101
Cross Test Plug	125B	084-113-101
Cutout Test Plug	123B	084-113-101
Sleeve Limiting	33	084-101-101
Sleeve	34	084-101-101
92- and 292-Type Jacks		
Butt Test Plug	114B	084-111-101
Cross Test Plug	115B	084-113-101
Cutout Test Plug	113B	084-111-101
Sleeve Limiting	39	084-101-101
Sleeve	40	084-101-101
216-, 218-, and 303-Type		
Sleeve Limiting Gauge	155A	084-120-101
Spring Test Plug	157A	084-120-101
230-, 240-, 242-, and 267A-Type		
Jacks, Sleeve Limiting Gauge	155A	084-120-101
513-, 514-, 545-, and 556-Type		
Jack Spring Test Plug	197A	084-128-101

K

KS-Specifications

Watch, Stop, Decimal	KS-1894	084-870-101
Watch, Stop	KS-1894	084-870-101
Gauge, Vacuum	KS-3008	084-870-101
Hydrometer, Syringe	KS-5499	084-540-101
Thermometer, Non-Floating	KS-5499	084-550-101
Weights, Gram	KS-6338	084-750-101
Gauge, Vacuum	KS-6584	084-540-101
Gauge, Thickness	KS-6909	084-550-101
Gauge, Thickness	KS-6938	084-550-101
Meter, Percent Break	KS-7361	084-640-101
Counter, Impulse	KS-7608	084-510-101
Volt-Milliammeter, DC		
Special Model 622	KS-8039	084-800-101
Milliammeter	KS-8529	084-645-101
External Shunts	KS-9442	084-700-101
Gauge	KS-14320	084-545-101

DESCRIPTION	CODE	SECTION
Volt-Ohm-Milliammeter	KS-14510	084-810-101
Voltmeter	KS-15538	084-800-101
Gauge	KS-16837	084-545-101
Volt-Ohm-Milliammeter	KS-16979	084-810-101
Voltmeter, DC	KS-19178,L1	084-805-101
Ammeters	KS-19516,L1	084-501-101
	KS-19516,L2	084-501-101
	KS-19516,L3	084-501-101
	KS-19516,L4	084-501-101
	KS-19516,L5	084-501-101
	KS-19516,L6	084-501-101
Milliammeter	KS-19556,L1	084-645-101
Ammeters	KS-19563,L1	084-505-101
	KS-19563,L2	084-505-101
	KS-19563,L3	084-505-101
	KS-19563,L4	084-505-101
Gauge, Locating, 1A Card Writer	KS-19873,L1	084-540-101
	KS-19874,L1	084-540-101
	KS-19876,L1	084-540-101
	KS-19877,L1	084-540-101
Pawl Gauge, 1A Card Writer	KS-19878,L1	084-540-101
S6, S7, and S8 Switch Adjustment, 1A Card Loader	KS-19907,L1	084-540-101
Gauge, Locating, 1A Card Writer	KS-19908,L1	084-540-101
S2 Switching Adjustment, 1A Card Loader	KS-19910,L1	084-540-101
Gauge, Head Alignment, 1A Card Writer	KS-20226,L1	084-540-101
Frequency Meter	KS-20364,L1	084-640-101
Volt-Ohm Milliammeter	KS-20538,L1	084-810-101
Voltmeter, Digital	KS-20599,L4	084-810-101
Height Gauge, Step-By-Step	KS-20606	084-540-101
Gauge, Non-Trapping, CA-CF, Small Crossbar Switches	KS-20650	084-545-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
L		
Levels		
Bench, Adjustable 6-inches	R-1258	084-600-101
Bench, Adjustable 12-inches	R-1257	084-600-101
Metallic, 2-1/2 inches		084-600-101
Limiting Gauges		
49- and 141-Type Jacks	33	084-101-101
	34	084-101-101
92-Type Jacks	40	084-101-101
92- and 292-Type Jacks	39	084-101-101
110-Type Plugs	28	084-101-101
Step-by-Step Banks	D-158526	084-540-101
Line Switch Plunger		
Gauge Block, AECo	H-7541-3	084-510-101
Locating Gauges		
1A Card Writer	KS-19873,L1	084-540-101
	KS-19874,L1	084-540-101
	KS-19876,L1	084-540-101
	KS-19877,L1	084-540-101
	KS-19908,L1	084-540-101
Armature	149B	084-120-101
	162B	084-122-101
Interrupter	76	084-105-101
Timer, Off-Normal Cam	143A	084-117-101
M		
Manometers		
36-inch	R-3076	084-600-101
4-inch, Manning, Maxwell and Moore, Inc.....	Model 1370	084-600-101
Megger, Tester, Insulations, Briddle Co.,	Model 7679S	084-600-101
Memory Card	3A	084-600-101
Meters		
Frequency, Frahm		
15-30 Cycles	6230	084-640-101
20-80 Cycles	6300	084-640-101
	KS-20364,L1	084-640-101
Percent Break	KS-7361	084-640-101

DESCRIPTION	CODE	SECTION
See Also Ammeter, Micro-Ammeter, Milliammeter, Ohm-Meter, Voltammeter, Voltmeter, Voltmilliammeter, Volt-Ohm-Milliammeter, and Voltohmyst.		
Microammeters		
Weston	Model 622	084-640-101
Micrometer, Inside, Brown and Sharpe	263	084-640-101
Milliammeter	KS-19556,L1	084-645-101
Milliammeters, Weston, DC		
Ranges		
600	Model 1	084-645-101
1.5	Model 281	084-645-101
5	Model 281	084-645-101
10	Model 281	084-645-101
50	Model 281	084-645-101
75	Model 281	084-645-101
Millivoltmeter, Weston, DC		
Range 100MV	Model 281	084-645-101
Millivoltmeter, dc, Sensitive		
Model Bellud		084-645-101
Multipliers, Weston		
Voltmeter		
300 Volts	Model 280 or 281	084-645-101
600 Volts	Model 280 or 281	084-645-101
O		
Off-Normal Cam Location		
Gauge	143A	084-117-101
Overlap Gauge, Armature	160A	084-120-101
P		
Pawl, 1A Card Writer	KS-19878,L1	084-540-101
Percent, Break Meter	KS-7361	084-640-101
Plug Gauges		
Double-end		
197 and 198 Switches	130A	084-115-101
Limiting, 110-Type Plugs	28	084-101-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
Overall Checking		
109 and 309 Plugs	106A	084-111-101
110 and 310 Plugs	111A	084-111-101
Positioning Gauge, Selecting Finger, See Selecting Finger Positioning Gauge.		
Push-Pull Tension Gauges		
0-200	79C	084-105-101
0-1000	79B	084-105-101
0-6000	79F	084-105-101
Pyropoint, Alnor, Illinois Testing Labs		
Range 0-2000°F	Model 1645	084-600-101
R		
Resistor, 2-Ohm, Ward-Leonard		084-645-101
Resistor, 2 and 3-Ohm, Ward-Leonard		084-645-101
R-Specifications		
Thermometers		
-5° to 150°	R-1032 Det. 1	084-750-101
Level, Bench, Adjustable		
12-Inches	R-1257	084-600-101
6-Inches	R-1258	084-600-101
Gauge, Bracket, Squaring	R-1306	084-540-101
Straightedge, Steel 3 feet	R-1653	084-700-101
Gauge, Dial Indicator	R-2040	084-540-101
Gauge, Thickness, 0.045 inch	R-2058	084-545-101
Balance Spring, 0 to 3 Lbs.	R-2202	084-510-101
Gauge, Thickness, 0.105 inch to 0.125 inch	R-2310	084-545-101
Gauge, Thickness 0.015 inch	R-2441	084-545-101
Balance Spring, 0 to 30 Lbs.	R-2481	084-510-101
Balance Spring, 0 to 6 Lbs.	R-2771	084-510-101
Manometer, 36 inches	R-3076	084-600-101
Gauge, Thickness, 0.004 inch and 0.008 inch	R-3267	084-545-101
Gauge, Vertical Drive Shaft Alignment	R-5320	084-540-101
Tape, Steel, 50-Foot	R-7860	084-700-101
Scale, Steel, 6 inches	R-8550	084-645-101
Gauge, Thickness, Double-End, Double Step 0.030 inch, 0.045 inch, 0.060 inch, 0.120 inch	R-80223	084-545-101
Rod, Brush Gauge	108A	084-111-101
Rule, Measuring, 6-Foot	AT-6911	084-645-101

DESCRIPTION	CODE	SECTION
S		
Scales		
8-ounce	TP110443	084-645-101
32-ounce	TP110444	084-645-101
4-Lbs.	TP82711	084-645-101
15-Lbs.	TP135059	084-645-101
Steel 6-inches	R-8550	084-645-101
Screw Gap Gauge	150B	084-120-101
Selecting Finger		
Positioning Gauges	164A	084-122-101
	164B	084-122-101
	165A	084-122-101
Shunts		
Portable Test	KS-9442	084-700-101
Spring Balances, See Balances.		
Squares		
Combination, 12-inch		084-700-101
Steel, No. 14		084-700-101
Steel, No. 18		084-700-101
Squaring Gauge, Vertical		
Drive Shafts	R-1306	084-540-101
Stop Watch, See Watches.		
Straightedges		
Steel, 3-inch	R-1653	084-700-101
Steel, Stanley No. 18		084-700-101
Stud Gap Gauge	133A	084-115-101
Switch Adjustment		
1A Card Loader	KS-19907,L1	084-540-101
	KS-19910,L1	084-540-101

T

Tachometers		
No. 560, James G. Biddle Co.		084-700-101
Tape, Steel, 50-Foot	R-7860	084-700-101
Targets	2A	084-700-101
	2B	084-700-101
	2C	084-700-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
Terminal Locating Gauge, Bank	116A	084-113-101
Testers, Solution, Anti-Freeze Edelmann	Model 808	084-700-101
	Model 909	084-700-101
Tester, Voltage	840468664	084-700-101
Test Indicator, Universal Type, Starrett	196A	084-600-101
Test Plugs for Jacks, See Jack Gauges.		
Thermometers		
—5° to 150°C	R-1032 Det. 1	084-750-101
—10° to +400°C, Fisher Scientific		084-750-101
—20° to 120°F	AT-6639N	084-750-101
0° to 230°F, Fisher Scientific		084-750-101
20° to 120°F	KS-5499	084-750-101
Thickness Gauges		
0.0015	92R 172A 183A KS-6909	084-109-101 084-125-101 084-127-101 084-550-101
0.002	75F 92S 186A KS-6909	084-105-101 084-109-101 084-127-101 084-550-101
(Flat)	TP96356	084-540-101
(Flat)	TP96358	084-540-101
0.003	67G 75B 92P 172B KS-6909	084-103-101 084-105-101 084-109-101 084-125-101 084-550-101
(Flat)	TP93833	084-540-101
0.0035	172C 183B	084-125-101 084-127-101
0.004	67H 75C 110A 127A 132AF KS-6909	084-103-101 084-105-101 084-111-101 084-115-101 084-115-101 084-550-101

DESCRIPTION	CODE	SECTION
(Flat)	R-3267	084-545-101
	TP93822	084-540-101
0.0045	172D	084-125-101
	182A	084-127-101
0.005	67K	084-103-101
	75D	084-105-101
	85A	084-107-101
	92T	084-109-101
	100A	084-109-101
	110A	084-111-101
	140A	084-117-101
	172E	084-125-101
	183C	084-127-101
(Flat)	KS-6909	084-550-101
	TP93823	084-540-101
0.006	67L	084-103-101
	75E	084-105-101
	92U	084-109-101
	117A	084-113-101
	132AG	084-115-101
	186B	084-127-101
	KS-6909	084-550-101
(Flat)	TP96360	084-540-101
(Round)	TP96309	084-540-101
0.007	73B	084-105-101
	75J	084-105-101
	129A	084-115-101
	172F	084-125-101
	174C	084-125-101
	182B	084-127-101
	KS-6909	084-550-101
(Flat)	TP96362	084-540-101
0.008	67J	084-103-101
	73B	084-105-101
	75N	084-105-101
	92W	084-109-101
	117A	084-113-101
	132A	084-115-101
	168A	084-125-101
	186C	084-127-101
	KS-6909	084-550-101
	R-3267	084-545-101
(Round)	TP96371	084-540-101

SECTION 084-000-001

	DESCRIPTION	CODE	SECTION
0.0085	172G	084-125-101
0.009	75K	084-105-101
		126A	084-115-101
		148G	084-120-101
		KS-6909	084-550-101
0.010	67M	084-103-101
		75M	084-105-101
		80B	084-105-101
		92A	084-109-101
		100B	084-109-101
		132B	084-115-101
		134A	084-115-101
		172H	084-125-101
0.011	75L	084-105-101
		174C	084-125-101
		KS-6909	084-550-101
0.012	75G	084-105-101
		77B	084-105-101
		103A	084-109-101
		138A	084-117-101
		148A	084-120-101
		172J	084-125-101
		KS-6909	084-550-101
(Round)	TP93828	084-540-101
0.013	73D	084-105-101
		92B	084-109-101
		132C	084-115-101
		168C	084-125-101
		KS-6909	084-550-101
0.0135	172K	084-125-101
0.014	77B	084-105-101
		85H	084-107-101
		91A	084-107-101
		103A	084-109-101
		KS-6909	084-550-101
		KS-16837	084-545-101
0.0145	172L	084-125-101
0.015	42	084-101-101
		67A	084-103-101
		80B	084-105-101
		85F	084-107-101
		92E	084-109-101

DESCRIPTION	CODE	SECTION
0.015 (Contd).....	.97A	084-109-101
	100C	084-109-101
	103A	084-109-101
	126A	084-115-101
	127B	084-115-101
	132D	084-115-101
	140D	084-117-101
	148B	084-120-101
	183D	084-127-101
	KS-6909	084-550-101
	R-2441	084-545-101
(Round)	TP96375	084-540-101
0.016.....	.43	084-101-101
	82B	084-107-101
	85J	084-107-101
	110B	084-111-101
	168D	084-125-101
	172M	084-125-101
	KS-6909	084-550-101
0.0165	183E	084-127-101
1/64-inch.....		084-107-101
0.01773D	084-105-101
	132E	084-115-101
	KS-6909	084-550-101
0.01873A	084-105-101
	75H	084-105-101
	85K	084-107-101
	92D	084-109-101
	132AE	084-115-101
	138B	084-117-101
	KS-6909	084-550-101
(Round)	TP93824	084-540-101
0.019168E	084-125-101
	KS-6909	084-550-101
0.02067B	084-103-101
	80B	084-105-101
	91B	084-107-101
	92G	084-109-101
	95A	084-109-101
	100D	084-109-101
	132F	084-115-101
	140C	084-117-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
0.020 (Contd).....	186D	084-127-101
	KS-6909	084-550-101
(Round)	TP96377	084-540-101
0.021	168F	084-125-101
	KS-6909	084-550-101
0.0215	172N	084-125-101
0.022	73A	084-105-101
	87A	084-107-101
	92F	084-109-101
	140F	084-117-101
	168G	084-125-101
	186E	084-127-101
	KS-6909	084-550-101
0.023	67N	084-103-101
	132G	084-115-101
	172P	084-125-101
	KS-6909	084-550-101
0.024	82B	084-107-101
	85D	084-107-101
	140B	084-117-101
	168B	084-125-101
	172H	084-125-101
	KS-6909	084-550-101
	KS-16837	084-545-101
(Flat)	TP96364	084-540-101
(Round)	TP96373	084-540-101
0.025	67C	084-103-101
	92H	084-109-101
	97A	084-109-101
	100E	084-109-101
	140E	084-117-101
	148C	084-120-101
	KS-6909	084-550-101
(Round)	TP93825	084-540-101
0.0255	172R	084-125-101
0.026	132H	084-115-101
	175A	084-125-101
	KS-6938	084-550-101
0.0265	183F	084-127-101
0.027	172S	084-125-101
	KS-6938	084-550-101

DESCRIPTION	CODE	SECTION
0.028	183G	084-127-101
	KS-6938	084-550-101
0.029	132J	084-115-10
	KS-6938	084-550-101
0.030	67D	084-103-101
	80B	084-105-101
	87B	084-107-101
	90	084-107-101
	92J	084-109-101
	100F	084-109-101
	101A	084-109-101
	126C	084-115-101
	KS-6938	084-550-101
	R-80223	084-545-101
(Round)	TP93811	084-540-101
0.031	168H	084-125-101
	172T	084-125-101
	KS-6938	084-550-101
0.032	132K	084-115-101
	141A	084-117-101
	175A	084-125-101
	KS-6938	084-550-101
0.0325	172U	084-125-101
0.033		084-550-101
0.034	41	084-101-101
	85E	084-107-101
	168J	084-125-101
	KS-6938	084-550-101
0.035	67E	084-103-101
	80B	084-105-101
	92K	084-109-101
	100G	084-109-101
	101B	084-109-101
	132L	084-115-101
	KS-6938	084-550-101
(Round)	TP96383	084-540-101
0.036	77C	084-105-101
	KS-6938	084-550-101
0.0365	172W	084-125-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
0.037	168K	084-125-101
	170A	084-125-101
	KS-6938	084-550-101
(Round)	TP98136	084-540-101
0.038	132M	084-115-101
	168T	084-125-101
	172Y	084-125-101
	KS-6938	084-550-101
0.039	KS-6938	084-550-101
	KS-14320	084-545-101
0.040	67F	084-103-101
	77C	084-105-101
	87A	084-107-101
	92L	084-109-101
	100H	084-109-101
	101C	084-109-101
	112A	084-111-101
	126C	084-115-101
	132AH	084-115-101
	168L	084-125-101
	KS-6938	084-550-101
(Round)	TP96385	084-540-101
0.041	132N	084-115-101
	KS-14320	084-545-101
0.042	188A	084-127-101
0.043	170A	084-125-101
0.044	132P	084-115-101
0.045	67P	084-103-101
	87B	084-107-101
	92M	084-109-101
	R-2058	084-545-101
	R-80223	084-545-101
(Round)	TP96389	084-545-101
0.047	132R	084-115-101
0.048	141A	084-127-101
	188B	084-127-101
0.049	188C	084-127-101
0.050	92N	084-109-101
	101D	084-109-101

DESCRIPTION	CODE	SECTION
0.050 (Contd).....	105A	084-111-101
	112A	084-111-101
	132S	084-115-101
	148D	084-120-101
	161A	084-120-101
	169A	084-125-101
(Round)	TP96391	084-540-101
0.052	168N	084-125-101
0.053	132T	084-115-101
	142A	084-117-101
0.055	148E	084-120-101
(Round)	TP93827	084-540-101
0.056	132U	084-115-101
0.059	132W	084-115-101
0.060	91C	084-107-101
	101E	084-109-101
	132AJ	084-115-101
	142A	084-117-101
	A27580	084-540-101
	R-80223	084-545-101
(Round)	TP96393	084-540-101
0.062	132Y	084-115-101
	145A	084-117-101
0.065	107A	084-111-101
	132AA	084-115-101
	145A	084-117-101
	148F	084-120-101
(Round)	TP96399	084-540-101
0.068	118A	084-113-101
	132AB	084-115-101
0.070	169A	084-125-101
(Round)	TP96401	084-540-101
0.071	132AC	084-115-101
0.074	132AD	084-115-101
0.075 (Round)	TP96403	084-540-101
0.076	168P	084-125-101
0.080	83B	084-107-101

SECTION 084-000-001

DESCRIPTION	CODE	SECTION
(Round)	TP96405	084-540-101
0.082	119A	084-113-101
0.083	168S	084-125-101
0.084	168U	084-125-101
0.088	118A	084-113-101
0.090	168R	084-125-101
0.092	119A	084-113-101
0.094	161A	084-120-101
0.100	83B	084-107-101
	105A	084-111-101
	137A	084-117-101
0.105	R-2310	084-545-101
0.110	84B	084-107-101
0.118	137A	084-117-101
0.120	84B	084-107-101
	R-80223	084-545-101
0.123	126E	084-115-101
0.125	R-2310	084-545-101
0.129	126E	084-115-101
0.160	TP91681	084-545-101
0.178	173A	084-125-101
0.180	TP91681	084-545-101
0.191	173A	084-125-101
0.247	104A	084-109-101
0.250	110B	084-111-101
Thickness Gauge Nests	43	084-101-101
	66D	084-103-101
	74D	084-105-101
	99A	084-109-101
	131A	084-115-101
	139A	084-117-101
	171A	084-125-101
	184A	084-127-101
	185A	084-127-101
	187A	084-127-101

DESCRIPTION	CODE	SECTION
Thickness Gauge Nests (Contd)	KS-6909	084-550-101
	KS-6938	084-550-101
	TP117781	084-540-101
Timer, Standard Electric Time Company	S1	084-750-101
Transformers, Current Weston	Model 461	084-755-101
	Model 539	084-755-101
Tuning Forks	11A	084-755-101
	12A	084-755-101
	TP103628	084-755-101
V		
Vacuum Gauges	KS-5459	084-540-101
	KS-6584	084-540-101
U.S. Gauge Company	501	084-540-101
Volt-Ammeter, Weston, DC	Model 281	084-800-101
Voltmeter, Weston Ranges		
Volts (DC) 3, 75, 150	Model 301	084-805-101
Volts (AC) 5, 25, 250	Model 330	084-801-101
Volts (AC) 150 and 300	Model 528	084-801-101
Volts (AC/DC) 3, 30, 150, 300	Model 622	084-805-101
Volts (AC) 150 and 300	Model 904	084-801-101
Volts (DC) 3, 30, 50, 75, 150, 300	Model 931	084-805-101
Electronic, Ballantine U/3 (AC)	Model 300	084-800-101
Vacuum Tube, Hewlett-Packard	Model 400D	084-801-101
	Model 3400A	084-801-101
Voltmeters	KS-15538,L4	084-801-101
	KS-15538,L6	084-801-101
	KS-19178	084-801-101
Digital	KS-20599,L4	084-810-101
See Also Volt-Ammeter, Volt-Milliammeter, Volt-Ohm- Milliammeter, and Voltohmyst.		
Volt-Milliammeter (DC) Special Model 622	KS-8039	084-800-101
Volt-Ohm-Milliammeter	KS-14510	084-810-101
Voltohmyst, Senior	98C	084-810-101

SECTION 084-000-001

DESCRIPTION

CODE

SECTION

W

Watch, Stop	KS-3008	084-870-101
Decimal	KS-1894	084-870-101
Wattmeter, Polyphase	Model 329	084-870-101
Wedge Gauge	179A	084-127-101
Weights		
Cord, 325 Gram	121A	084-870-101
Gram93B	084-109-101
Gram	KS-6338	084-870-101
Wire, Gauge		
0.060 inch and 0.065 inch	TP91270	084-540-101