

POWER SYSTEMS

EQUIPMENT TEST LIST

FOR

TONE ALTERNATORS AND TONE MACHINES

AND

RINGING AND COIN CONTROL GENERATORS

SEE SECTION 010-300-011 FOR EQUIPMENT TEST LIST INSTRUCTION.

EQUIPMENT TEST LIST						
B.S.P.	I S S	TEST OR REQT.	EQUIPMENT AND WORK DESCRIPTION	CLASS	FREQ.	JOB NO.
155-310-701	2		A. E. CLASS OF SERVICE			
			TONE MACHINE			
		2.02	<i>Lubrication</i>			
		(a)	<i>Lubricate Cam</i>	MW	3M	
		(b)	<i>Check Oil Level in Gear Case</i>	MW	3M	
		(c)	<i>Lubricate Motor Bearings</i>	MW	M	
		(e)	<i>Change Oil in Gear Case</i>			
			<i>KS-2245 Oil</i>	MW	24M	
			<i>KS-16326 Oil</i>	MW	5Y	
			<i>Mixture KS-2245 and KS-1632 Oil</i>	MW	24M	
		2.05	<i>Check Contact Separation</i>	MW	12M	
		2.06	<i>Check Contact Spring and Cam Spring</i>			
			<i>Separation</i>	MW	12M	
		2.07	<i>Check Spring Tension</i>	MW	12M	
155-405-301	1		GENERATORS RINGING AND COIN CONTROL			
			P TYPE (NON-CODED)			
		2.14	<i>Transfer and Restore Load—</i>	MW	W	
			<i>One-Motor Set With Auto Transfer</i>			
		2.20	<i>Transfer and Restore Load—</i>	MW	W	
			<i>One-Motor Set Without Auto Transfer</i>			
		2.24	<i>Transfer and Restore Load—</i>	MW	W	
			<i>Two-Motor Set</i>			
		2.28	<i>Stopping Machine—One-Motor Set</i>			
			<i>With or Without Auto Transfer</i>			
		2.32	<i>Stopping Machine—Two-Motor Set</i>			
155-405-701	3		GENERATORS—RINGING AND COIN CONTROL			
			P TYPE (NONCODED)			
		2.01	<i>Check Oil in Bearing and Gear</i>	MW	W	
			<i>Reduction Box</i>			
			<i>Replace Oil in Bearings and</i>	MW	24M	
			<i>Reduction Box</i>			
		2.09	<i>Check Brush Length</i>	MW	12M	
		2.11	<i>Check Brush Pressure</i>	MW	12M	
		2.14	<i>Clean and Inspect Commutator and</i>	MW	W	
			<i>Collector Ring Surfaces</i>			
		2.16	<i>Check for Noise and Vibration</i>	MW	W	
		2.17	<i>Check Temperature (By Feel)</i>	MW	W	

