

## DC-TO-DC CONVERTERS

J87248C

### OPERATING METHODS

#### 1. GENERAL

**1.001** This addendum supplements Section 161-285-302, Issue 1. This addendum does not affect the Equipment Test List.

**1.002** This addendum is issued to change the information in 3E to permit safe starting of converters if the total load on a group is greater than 40 amperes.

#### 3. METHODS

##### E. Parallel Operation Adjustment (see 1.09)

The following addition applies to Part 3 of the section:

**Add:**

**Note 1: For Starting Only:** If the total load on a group of converters is greater than

40 amperes, remove the associated load distributing fuses prior to starting of the group. Prior to applying parallel operation adjustments, replace the associated load distributing fuses.

**Change:**

**Note:** This adjustment is made while the converters are in service. Avoid all contact with terminal. Voltages over 150 volts to ground are possible.

**To Read:**

**Note 2:** This adjustment is made while the converters are in service. Avoid all contact with terminal. Voltages over 150 volts to ground are possible.