

**NO. 1 ELECTRONIC SWITCHING SYSTEM APPLICATION**  
**EMERGENCY ACTION PROCEDURE**  
**NO. 2 SWITCHING CONTROL CENTER SYSTEM**

**1. GENERAL**

**1.001** This addendum supplements Section 190-113-340, Issue 1. Place this pink sheet ahead of Page 1 of this section.

**1.002** This addendum is issued for the following reason:

- (a) Change the title format.
- (b) Remove the reference to 1A (CC1A).
- (c) Change CC1A to read control console.

**2. CHANGE TO SECTION**

**2.001** On Page 1, reformat title to read No. 1 Electronic Switching System Application on the first line; Emergency Action Procedure (with the reference to CC1A deleted) on the second line, and No. 2 Switching Control Center System on the third line.

**2.002** On Page 2, paragraph 2.01, delete the reference to No. 1A (CC1A).

**2.003** On Page 1 and throughout this section change CC1A to read control console. The control console in this section may be a CC1A, CC2A, etc. The CC1A changes are at the following locations:

- (a) On Page 2, paragraph 2.01, change CC1A to read control console.
- (b) On Page 2, paragraph 2.03, change CC1A to read control console.
- (c) On Pages 2 and 3, paragraph 2.06, subparagraphs (2), (3), and (6), change CC1A to read control console.
- (d) On Page 3, paragraph 2.07, change both appearances of CC1A to read control console.

- (e) On Page 3, paragraph 3.02, change CC1A to read control console.
- (f) On Page 3, paragraph 3.03, change CC1A to read control console.
- (g) On Page 3, paragraph 3.04, change CC1A to read control console.
- (h) On Page 3, paragraph 5.02, change CC1A to read control console.
- (i) On Page 3, paragraph 5.03, change CC1A to read control console.
- (j) On Page 6, Fig. 2, in the second block down from the entry symbol 2, change the three appearances of CC1A to read control console.
- (k) On Page 7, Fig. 2, in the left column under the entry symbol 3, change CC1A in the second and fourth blocks to read control console.
- (l) On Page 7, Fig. 2, in the right column, change CC1A in blocks 1, 2, 6, and 8 to read control console.
- (m) On Page 9, Fig. 2, in the first block under the entry symbol 6, change CC1A to read control console.
- (n) On Page 10, Fig. 2, in fifth block under the entry symbol 8, change CC1A to read control console.
- (o) On Page 11, Fig. 2, in sixth block under the entry symbol 9, change CC1A to read control console.
- (p) On Page 12, Fig. 2, in third block under the entry symbol 10, change CC1A to read control console.
- (q) On Page 13, Fig. 2, in third block under the entry symbol 11, change CC1A to read control console.

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement

**ADDENDUM 190-113-341**

- (r) On Page 14, Fig. 2, in fifth block under the entry symbol 12, change CC1A to read control console.
- (s) On Page 15, Fig. 2, in fifth block under the entry symbol 13, change CC1A to read control console.
- (t) On Page 17, Fig. 2, in first block under the entry symbol 15, change CC1A to read control

console.

- (u) On Page 18, Fig. 2, in sixth block under the entry symbol 17, change CC1A to read control console.
- (v) On Page 18, Fig. 2, in second block under the entry symbol 18, change CC1A to read control console.