

REPLACING PAGE ADDENDUM

Filing Instructions:

1. REMOVE FROM THE SECTION THE PAGES NUMBERED THE SAME AS THOSE ATTACHED TO THIS PINK SHEET.
2. INSERT THE ATTACHED PAGES INTO THE SECTION IN THEIR PLACE.
3. PLACE THIS PINK SHEET AHEAD OF PAGE 1 OF THE SECTION.

TRANSLATORS
TESTS USING OFFICE TEST FRAME
TEST CIRCUIT SD-27633-01 (J23260)
NO. 5 CROSSBAR OFFICES
ARRANGED FOR LAMA OR ANI

1. GENERAL

1.001 This addendum supplements Section 218-471-501, Issue 2. The attached page must be inserted in the section in accordance with the filing instructions above.

1.002 This addendum is issued to make a minor revision to Test G. This addendum does not affect Equipment Test Lists.

4. METHOD

The following change applies to Part 4 of the section:

- (a) Test G, revised

Attached:

Page 13 reissued December 1971

Page 14 revised December 1971

STEP	ACTION	VERIFICATION
18a	Operate ST key.	Call completed to test line number. At jack, lamp, and key circuit— AMAT- lamp associated with translator made busy remains lighted.
19a	At OTF— Restore ST key.	All lamps extinguished.
20a	Set A- through N- DIAL switches to select an AMA route to any test line number having a message billing 9.	
21a	Operate ST key.	Overflow tone heard. At jack, lamp, and key circuit— AMAT- lamp associated with translator made busy remains lighted.
22a	At OTF— Restore ST key.	Overflow tone silenced. All lamps extinguished.
23a	At jack, lamp, and key circuit— Remove make-busy plug from AMAT- or TRNSL- make-busy jack.	
24b	If office is arranged for ANI— Set A- through N- DIAL switches to select an ANI route to any test line number.	
25b	Set A- SDR switch as required for identifying digit.	
26b	Set B- through H- SDR switches for directory number of line used in test.	
27b	Operate 8SD, ANI keys.	
28b	Operate ST key.	Call completed to operator for identification of calling number. <i>Note:</i> Inform operator that this is a test call and proceed to next step.
29b	Restore ST key.	Call disconnected.
30b	At jack, lamp, and key circuit— Remove make-busy plug from AMAT- or TRNSL- make-busy jack.	
31	At OTF— Restore all keys and switches not required in next test.	

*

SECTION 218-471-501

STEP	ACTION	VERIFICATION
G. Transverter Preference Chain Transfer and Alarm		
1	At translator frame under test— Restore TR key if operated.	TRT, TR- relays released.
2	Insulate 8B of TRT relay.	CH relay momentarily operated. CH, aisle pilot lamps lighted. Minor alarm sounds.
3	Remove insulator from TRT relay.	
4	Momentarily operate (push in) AR key.	CH, aisle pilot lamps extinguished. Minor alarm silenced.
5	Insulate 4B of TRT relay.	CH1 relay momentarily operated. CH, aisle pilot lamps lighted. Minor alarm sounds.
6	Remove insulator from TRT relay.	
7	Momentarily operate (push in) AR key.	CH, aisle pilot lamps extinguished. Minor alarm silenced.
8	Insulate 6B of TRT relay.	CH, CH1 relays ♦momentarily♦ operated. CH, aisle pilot lamps lighted. Minor alarm sounds.
9	Remove insulator from TRT relay.	
10	Momentarily operate (push in) AR key.	CH, aisle pilot lamps extinguished. Minor alarm silenced.
11	Operate TR key.	TRT, TR- relays operated.
12	Restore TR key.	TRT, TR- relays released.

H. TB Lead Ground Detection

1	At translator frame under test— Momentarily connect ground to punching 20 on terminal strip A.	XTB, aisle pilot lamps lighted. Minor alarm sounds.
2	Momentarily operate RXTB key.	XTB, aisle pilot lamps extinguished. Minor alarm silenced.

i. Overlap

Caution: The bulk billed calls made by the customers served by the translator being tested will be completed without a charge record and detail billed calls will be routed to overflow. In ANI offices, calls