

ALPHABETICAL INDEX

NO. 5 CROSSBAR OFFICES

ARRANGED WITH CALL DATA TRANSMITTER

1. GENERAL

- 1.01 This section provides an alphabetically arranged list of all subjects and procedures for the call data transmitter (CDT) in No. 5 crossbar offices.
- 1.02 This section does not affect the Equipment Test Lists.
- 1.03 For reference to miscellaneous apparatus and methods, such as relay adjusting, etc, see the Master Alphabetical Index for all divisions, BSP 000-000-001.
- 1.04 Refer to Section 218-000-000 for testing equipment in No. 5 crossbar offices other than those covered in this section.

SECTION

SECTION

-A-

Acceptance Tests — MTF	218-779-103
Acceptance Tests — OTF	218-779-113
AIOD Tests — MTF	218-779-503
AIOD Tests — OTF	218-779-513
Alarms, Handling CDT	218-779-702
Audit, Data Base	218-779-307

-C-

Cutover Procedures — MTF	218-779-102
Cutover Procedures — OTF	218-779-112

-D-

DAS Diagnostics	218-779-301
DAS Status	218-779-301
Data Base (Wired — System Cross Connect)	
Audit	218-779-307
Diagnostic, System Cross-Connect	218-779-301
Scan/Distribute Verification	281-779-306

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

SECTION

SECTION

-D-

Diagnostics

DAS Bus 218-779-301
 DAS Scan/Distribute Board 218-779-301
 DAS Unit 218-779-301
 DTP Response 218-779-301
 Random Access Memory (RAM)..... 218-779-301
 Read Only Memory (ROM)..... 218-779-301
 Serial Input/Output Ports 218-779-301
 Sanity Timer 218-779-301
 System Cross-Connections 218-779-301
 Trouble Record 218-779-305

Diagnostic Test Panel

Functional Description & Usage..... 218-779-101
 Input/Output Messages..... 218-779-105
 Response Diagnostic..... 218-779-301

Directed Scan/Distribute

Directed Distribute Point Operation 218-779-301
 Directed Scan/Distribute — Word 218-779-301
 Directed Scan — Specific Trunk 218-779-301

-E-

Error Codes, Trouble Record 218-779-106

-G-

General Description — CDT 958-314-100

-I-

Initialization and Recovery, System 218-779-104
 Input Message — DTP 218-779-105
 Interface Tests, Marker, MTF 218-779-501
 Interface Tests, Marker, OTF 218-779-511

-M-

Marker Interface Tests — MTF 218-779-501
 Marker Interface Tests — OTF 218-779-511
 Marker Scan Lead Verification — MTF 218-122-534
 Marker Scan Lead Verification — OTF 218-423-514
 Marker Status 218-779-301

SECTION	SECTION
-O-	
On-line (Background) Diagnostics	218-779-301
Output Messages — DTP	218-779-105
-P-	
Plant Register Lead Verification	218-779-304
-R-	
Random Access Memory (RAM) Diagnostic	218-779-301
Read Only Memory (ROM) Diagnostic	218-779-301
Recovery, System Initialization and	218-779-104
-S-	
Sanity Timer Diagnostic	218-779-301
Serial Input/Output (SIO) Diagnostic	218-779-301
Serial Input/Output (SIO) Status	218-779-301
Status Request Procedures	218-779-301
Distribute and Scan (DAS)	
Completing Markers	
Serial Input/Output Ports	
System	
Translator Access Circuits	
System Cross-Connect Diagnostic	218-779-301
System Cross-Connect Scan/Distribute Verification	218-779-306
System Initialization & Recovery	218-779-104
System Status	218-779-301
-T-	
Taking CDT Equipment Out of Service	218-779-701
Traffic Register Lead Verification	218-779-304
Translator Access Circuit Tests — MTF	218-779-503
Translator Access Circuit Tests — OTF	218-779-513
Translator Access Circuit Status	218-779-301
Trouble Record Diagnostic	218-779-305