

DIMENSION[®] PBX FEATURE TEST
SPEED CALLING

CONTENTS

- 1. GENERAL
- 2. RECORDS
- 3. TEST EQUIPMENT
- 4. DOCUMENT

- 5. PREPARATION
- 6. PROCEDURE
 - 6.1 Add Number Out Dialed
 - 6.2 Test Speed Calling Feature

1. GENERAL

1.1 This section provides information to test the Speed Calling feature.

2. RECORDS

2.1 Form SD-97-1313 is required for recording the results of this test.

3. TEST EQUIPMENT

Qty	Code	Description
1	ITE-4208A	Telephone Hand Set (or 500/2500 type tel set and 249A Adapter)
1	ITE-9153L	Cord Assembly

4. DOCUMENT

4.1 COD - Customer Order Document.

5. PREPARATION

5.1 Select a station which is a controlling extension of speed calling list from Speed Calling Assignment of the COD.

5.2 Connect a telephone set to the selected controlling extension.

5.3 If the Number Out Dialed is listed in the COD, all trunks which are associated with the Trunk Dial Access Code of the Number Out Dialed to be tested are required to be connected to CO. Then perform step 6.2 for Testing Speed Calling feature.

5.4 If none of the Number Out Dialed is provided in the COD, a local test number can be used. Select a CO trunk group and add the trunk dial access code as the part of Number Out Dialed. All CO trunks of the selected CO trunk group should be cross-connected to CO. Then perform steps 6.1, 6.2 and 6.3.

6. PROCEDURE

6.1 Add Number Out Dialed to Controlling Extension Speed Calling List

6.1.1 Go off-hook at the controlling extension.

6.1.1.1 Verify that dial tone is heard.

6.1.2 Dial the Speed Calling Addition Access Code (dial access code can be obtained from Trunk and Feature Dial Code Summary of the COD).

6.1.3 Dial a "1" (List Entry Number 1).

6.1.3.1 Verify that second dial tone is heard.

6.1.4 Dial the selected trunk group access code and the local test number.

6.1.5 After the last digit is dialed wait (approximately 10 seconds) for the confirmation tone (recall dial tone) at the controlling extension.

6.1.6 Place the controlling extension on-hook.

ACCESS #2

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

Printed in U.S.A.

6.2 Test Speed Calling Feature

6.21 Go off-hook at the controlling extension.

6.211 Verify that dial tone is heard.

6.22 Dial the speed calling access code (see Trunk and Feature Dial Code Summary section of the COD for dial access code) and then dial the List Entry Number (such as 1, 2,..... 30).

6.221 Verify that call can be completed.

6.23 Go on-hook at the controlling extension.

6.24 If the removal of the temporary Number Out Dialed is required, perform step 6.3.

6.3 Removal of Temporary Number Out Dialed From The Speed Calling List Entry

6.31 Reload the program tape by momentarily depressing the ENABLE key at the alarm panel.

Manager, Denver PBX PECC