

DIMENSION[®] PBX
FEATURE TEST
TIMED REMINDERS

CONTENTS

1. GENERAL
2. RECORDS
3. TEST EQUIPMENT
4. PROCEDURE

1. GENERAL

1.1 Description

1.11 This section describes the tests to be performed whenever the Timed Reminder feature is provided.

1.12 The Timed Reminder is a feature in which the Attendant is automatically alerted after 30 seconds when a call on the console is waiting (Attendant Call Waiting) or the called party has not answered, or an incoming call is held on the console.

2. RECORDS

2.1 Form SD-97-1313 is required for recording the results of this test.

3. TEST EQUIPMENT

3.1 Handsets

<u>Amount</u>	<u>ITE</u>	<u>Description</u>
1	4208A	Telephone Handset

3.2 Telephone Sets

<u>Amount</u>	<u>Code</u>	<u>Description</u>
2	500D (or equiv.)	Telephone Sets

3.3 Cords

<u>Amount</u>	<u>Code</u>	<u>Description</u>
1	9153L	Cord Assembly

4. PROCEDURE

4.1 Test Procedure

4.101 Connect the handset via the 249A Adapter to a circuit pack test line associated with a station that is not restricted from the attendant.

4.102 Connect the two 500D type telephone sets to two other station lines and make a station-to-station call between them.

4.103 Go off-hook with the handset and then dial the attendant. After dial completion, verify:

- That the console ringer sounds.
- That a LOOP key, ATND lamp flashes.
- That the handset receives ring-back.

4.104 At the console, momentarily operate the LOOP key associated with the flashing ATND lamp. Verify:

- That the console ringer is silenced.
- That the ATND lamp lights steadily.
- That a transmission path exists between the handset and the console.

4.105 At the console, momentarily operate the HOLD key. Verify:

- That the LOOP key, HOLD lamp lights steadily.
- That the LOOP key, ATND lamp extinguishes.

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

Printed in U.S.A.

- 4.106 After approximately 30 seconds, verify that the LOOP key, HOLD lamp flashes.
- 4.107 At the console, momentarily operate the LOOP key associated with the flashing HOLD lamp. Verify:
- That the LOOP key, HOLD lamp extinguishes.
 - That the LOOP key, ATND lamp lights steadily.
- 4.108 At the console, momentarily operate the START key. Verify:
- That the console receives dial tone.
 - That the console SPLIT lamp lights steadily.
- 4.109 With the console dial, dial one of the stations used to make the station-to-station call. (See Step 4.102) after dial completion verify:
- That the console, receives a confirmation tone.
 - That the LOOP key, ATND and BUSY lamps light steadily.
 - That the SPLIT lamp extinguishes.
- 4.110 At the console, momentarily operate the RELEASE key. Verify:
- That the LOOP key, ATND lamp extinguishes.
 - That the BUSY and PA lamps light steadily.
- 4.111 After approximately 30 seconds, verify that the LOOP key, BUSY lamp flashes.
- 4.112 At the console, momentarily operate the LOOP key, associated with the flashing BUSY lamp. Verify:
- That the LOOP key, ATND and BUSY lamps light steadily.
- 4.113 At the console, momentarily operate the RELEASE key. Verify:
- That the LOOP key, ATND lamp extinguishes.
 - That the LOOP key, BUSY, and the PA lamps light steadily.
- 4.114 Go on-hook with both of the 500D telephone sets used to make the station-to-station call. (See Step 4.102) Verify:
- That the LOOP key, RING lamp lights steadily.
 - That the LOOP key, BUSY lamp extinguishes.
 - That one of the 500D telephone sets receives ringing (one that was dialed in Step 4.109).
- 4.115 After approximately 30 seconds, verify that the console LOOP key, RING lamp flashes.
- 4.116 Go on-hook with the handset, verify:
- That the console LOOP key, RING lamp extinguishes.
 - That the 500D telephone set no longer receives ringing.
- 4.117 This completes the testing of the Timed Reminder feature per this section.

Manager, Denver PBX PECC