

EQUIPMENT TEST LIST
MULTI-MG TRUNK ARRANGEMENT
ANALOG MULTIPLEX TERMINAL EQUIPMENT

	CONTENTS	PAGE
1. GENERAL	1
3.1 MMX-2C&L4 CARR - SPARE TRK ONLY	2
3.2 JMX & L5 CARR - SPARE TRK ONLY	2
3.3 MMX-1 & WLEL - SPARE TRK ONLY	2
3.4 MMX-2R&RADIO-SPARE TRUNKS ONLY	2

1. GENERAL

1.01 This practice provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table of contents. Test classification and frequency of periodic routine are also provided.

1.02 This Equipment Test List (ETL) is reissued to incorporate changes which are indicated by an arrow to the left of each line which has been changed.

1.03 Comments on this practice should be made by following the instructions in AT&T Practice 000-010-015.

1.04 Routine test information is arranged in the following order from left to right: Practice number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

1.05 Practice 010-300-011 provides Equipment Test List instructions.

9.0 1A RADIO DIG SYS

9.1 1A RADIO DIG SYS; OVERALL SYSTEM

FOR ALL UNITS

♦	356-454-520	(4/0)	1	DC POWER	MW 6M	-----
♦			2	TRANSMITTING TERMINAL PROCESSOR	MW 6M	-----
♦			3	RECEIVING TERMINAL PROCESSOR	MW 6M	-----
♦			4	SPAN ACCESS PANEL	MW 6M	-----
♦			5	LINE ERRORED SECONDS	MW M	-----

TROUBLE TESTS

	356-454-500	(4/0)		GENERAL TEST INFORMATION	TT	-----
	356-454-501	(4/0)		TRANSMITTER TESTS	TT	-----
	356-454-502	(3/0)		RECEIVER TESTS	TT	-----
	356-454-503	(3/0)		SWITCH STATUS & CONTROL PANEL	TT	-----
	356-454-504	(2/0)		DC-DC CONVERTER	TT	-----
	356-454-510	(4/0)		SYSTEM TEST	TT	-----
	356-454-511	(4/0)		IN-SERVICE TROUBLE LOCATING	TT	-----
	356-454-512	(3/0)		OUT-OF-SERVICE TROUBLE LOCATING	TT	-----
	356-454-530	(1/0)		PORTABLE TERMINAL TESTS	TT	-----