



NETWORK SYSTEMS

Alcatel SONET Multiplexer

1603/12 SM

Maintenance and Trouble Clearing
OC-3/OC-12 Add/Drop Multiplexer
Task Oriented Practices
TOP

NOTE

This manual applies to 1603/12 SM Version 3.0 software. Release notes describing revisions to this software may impact operations described in this manual.

Alcatel Part Number 650205-823-015
Issue 3, October 1994

1225 North Alma Road
Richardson, Texas 75081-2206 U.S.A.

THIS PRODUCT COMPLIES WITH D.H.H.S. RADIATION PERFORMANCE STANDARDS 21 CFR, 1040.10, FOR A CLASS 1 LASER PRODUCT.

DANGER

Invisible laser radiation is present when the optic connector is open. AVOID DIRECT EXPOSURE TO BEAM.

WARNING

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

NOTICE

The product specification and/or performance levels contained in this document are for information purposes only and are subject to change without notice. They do not represent any obligation on the part of Alcatel. Such obligations will only be committed to in a written sales agreement signed by Alcatel Network Systems, Inc.

Technical Support Telephone Number

Alcatel provides technical assistance telephone numbers. For technical assistance (8:00 AM to 5:00 PM EST), call 1-800-767-6500 or after hours emergencies 1-800-553-4084.

Documentation Support Telephone Number

Alcatel provides a telephone number for you to report errors or to ask questions about the information in this document. The support telephone number is 1-800-767-6500 (Ext. 6365) or 1-919-850-6365.

TABLE OF CONTENTS

Table of Contents
ALCL 363-203-015 **Issue 3** ■

1603/12 SM Maintenance and Trouble Clearing – Issue Control List (ICL-001)
ALCL 363-203-502 **Issue 3** ■