

**EQUIPMENT TEST LIST**  
**T1 LINES**  
**DIGITAL TRANSMISSION SYSTEMS**

CONTENTS	PAGE
<b>1. GENERAL</b> . . . . .	<b>1</b>
<b>3.1 END OFF.-PWRD FR ORB</b> . . . . .	<b>2</b>
<b>3.2 END OFF.-PWRD OTR END</b> . . . . .	<b>2</b>
<b>3.3 END OFF.-WITH DSX-1</b> . . . . .	<b>2</b>
<b>3.4 INT OFF.-PWRD FR ORB</b> . . . . .	<b>2</b>
<b>3.5 INT OFF.-PWRD OTR END</b> . . . . .	<b>3</b>
<b>3.6 PASSIVE FAULT LOCATE LINES</b> . . . . .	<b>3</b>
<b>3.7 T1 AUTOMATIC STANDBY UNIT</b> . . . . .	<b>3</b>
<b>3.8 TROUBLE TESTS</b> . . . . .	<b>3</b>

of contents. Test classification and frequency of periodic routine are also provided.

**1.02** This ETL is issued to incorporate changes which are indicated by an arrow to the left of each line which has been changed.

**1.03** Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

**1.04** Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

**1.05** Section 010-300-011 provides Equipment Test List instructions.

**1. GENERAL**

**1.01** This section provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement

## 3.0 T1 LINES

## 3.1 T1 LINES; END OFF.-PWRD FR ORB

## SELECT ONLY ONE CATEGORY

## IN SERVICE LINES (W/O DSX1)

◆	365-800-002 (3/0)	503	T1 LINE TEST	MW 3M	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	MAINTENANCE OR BACKBONE LINES W/O DSX1 E/W J98722E MAINT LINE				
	S				
◆	365-800-002 (3/0)	556	T1 LINE TEST	MW 3M	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	MAINTENANCE OR BACKBONE LINES W/O DSX1 W/O J98722E MAINT LINE				
	S				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	UNASSIGNED POWERED LINES W/O DSX1				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	ORB CONNECTED TO DSX-1				
◆	365-800-002 (3/0)	558	POWER LOOP TEST	MW 12M	-----

## 3.2 T1 LINES; END OFF.-PWRD OTR END

## SELECT ONLY ONE CATEGORY

## IN SERVICE LINES

◆	365-800-002 (3/0)	503	T1 LINE TEST	MW 3M	-----
	MAINTENANCE OR BACKBONE LINES E/W J98722E MAINT LINE STAT IND				
◆	365-800-002 (3/0)	556	T1 LINE TEST	MW 3M	-----
	MAINTENANCE OR BACKBONE LINES W/O J98722E MAINT LINE STAT IND				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
	UNASSIGNED POWERED LINES				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----

## 3.3 T1 LINES; END OFF.-WITH DSX-1

## SELECT ONLY ONE CATEGORY

## IN SERVICE LINES

◆	365-800-002 (3/0)	503	T1 LINE TEST	MW 3M	-----
	MAINTENANCE OR BACKBONE LINES E/W J98722E MAINT LINE STAT IND				
◆	365-800-002 (3/0)	556	T1 LINE TEST	MW 3M	-----
	MAINTENANCE OR BACKBONE LINES W/O J98722E MAINT LINE STAT IND				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
	UNASSIGNED POWERED LINES				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----

## 3.4 T1 LINES; INT OFF.-PWRD FR ORB

## SELECT ONLY ONE CATEGORY

## MAINTENANCE LINES E/W J98722E MTCE LINE STAT IND

◆	365-800-002 (3/0)	556	T1 LINE TEST	MW 3M	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	MAINTENANCE LINES W/O J98722E MTCE LINE STAT IND				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	UNASSIGNED POWERED LINES				
◆	365-800-002 (3/0)	503	TI LINE TEST	MW D	-----
◆		558	POWER LOOP TEST	MW 12M	-----
	3.5 T1 LINES; INT OFF.-PWRD OTR END				
	SELECT ONLY ONE CATEGORY				
	MAINTENANCE LINES E/W J98722E MTCE LINE STAT IND				
◆	365-800-002 (3/0)	556	T1 LINE TEST	MW 3M	-----
	MAINTENANCE LINES W/O J98722E MTCE LINE STAT IND				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
	UNASSIGNED POWERED LINES				
◆	365-800-002 (3/0)	503	T1 LINE TEST	MW D	-----
	3.6 T1 LINES; PASSIVE FAULT LOCATE LINES				
◆	FOR ALL UNITS				
◆	365-800-002 (3/0)	557	FAULT LOCATE LINE	MW 3M	-----
	3.7 T1 LINES; T1 AUTOMATIC STANDBY UNIT				
	FOR ALL UNITS				
	365-200-504 (1/0)	5	MAINTENANCE (NOT AFFECTING SERVICE)	MW M	-----
	3.8 T1 LINES; TROUBLE TESTS				
	TROUBLE TESTS				
	T1 LINES				
	365-200-503 (2/0)		J98713F LINE TERMINATING UNIT--TESTS	TT	-----
◆	365-800-002 (3/0)		ALL TROUBLE TESTS LISTED ON IXL-001	TT	-----
	T1 AUTOMATIC STANDBY				
	365-200-504 (1/0)	4	T1 AUTOMATIC STANDBY TROUBLE LOCATION	TT	-----