

EQUIPMENT TEST LIST
DIGITAL MULTIPLEX
DIGITAL TRANSMISSION SYSTEMS

	CONTENTS	PAGE
1. GENERAL	1
5.1 TYPE M1-2	2
5.2 TYPE M1C	2
5.3 TROUBLE TESTS	2

1. GENERAL

1.01 This section provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table of contents. Test classification and frequency of periodic routine are also provided.

1.02 This ETL is reissued to incorporate changes in paragraphs 5.1, 5.2, and 5.3. An arrow has been placed to the left of each line which has been changed.

1.03 Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

1.04 Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

1.05 Section 010-300-011 provides Equipment Test List instructions.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

5.0 DIGITAL MX

5.1 DIGITAL MX; TYPE M1-2

SELECT ONLY ONE CATEGORY

MONITOR CIRCUIT WITH PROT SW

365-600-500	(1/0)	1	POWER UNIT TEST	MW 6M	-----
365-600-502	(1/0)	1	MONITOR CIRCUIT TEST	MW 6M	-----
		3	MULDEM TEST	MW 6M	-----

MONITOR CIRCUIT WITHOUT PROT SW

365-600-500	(1/0)	1	POWER UNIT TEST	MW 6M	-----
365-600-502	(1/0)	2	MONITOR CIRCUIT TEST	MW 6M	-----
		3	MULDEM TEST	MW 6M	-----

5.2 DIGITAL MX; TYPE M1C

FOR ALL UNITS

365-672-000	(2/0)	002	PERFORM VIOLATION MONITOR CHECK (M1C BAY)	MW 6M	-----
		501	CHECK STANDBY SWITCHING (M1C BAY)	MW 6M	-----

5.3 DIGITAL MX; TROUBLE TESTS

TROUBLE TESTS

M1-2

365-600-503	(2/0)		M1-2 TROUBLE LOCATION	TT	-----
365-600-506	(1/0)		M1-2A AND M1-2B TROUBLE LOCATION	TT	-----

M1C

365-672-000	(2/0)	095	ALL TROUBLE TESTS LISTED ON TIL	TT	-----
-------------	-------	-----	---------------------------------	----	-------