

41060

WRITING SHELF



Table of Contents

Ordering Information	2
General Description	2
Installation	3
Technical Specifications	6
Warranty	8

About this Practice:

This practice has been reissued to:

- Add the 41060-12 option.

Reissued Practices: Updated and new content can be identified by a banner in the right margin.

Issue date: April 2000

UPDATED

CAUTION

- Install or remove modules from the shelf only when the power is off. If you install a module in the shelf with the power on, the internal circuitry may suffer damage and the product warranty will be void.
- Remove and install circuit boards only in a static-safe environment (use antistatic wrist straps, smocks, footwear, etc.).
- Keep circuit boards in their antistatic bags when they are not in use.
- Do not ship or store circuit boards near strong electrostatic, electromagnetic, magnetic, or radioactive fields.
- For more complete information on electrostatic discharge safety precautions, refer to Bellcore™ Technical Reference # TR-NWT-000870.

ORDERING INFORMATION

NEW OPTION

NOTE: This section lists the different options available for this product. To order any of the available options, contact Dantel Inside Sales through our toll-free number, **1-800-432-6835**.

OPTION NUMBER	FEATURES
B25-41060-00	Writing Shelf, 19" width; Flush-mount
B25-41060-11	Writing Shelf, 23" width; Flush-mount
B25-41060-12	Writing Shelf, 23" width; Pre-configured for 5" extension

GENERAL DESCRIPTION

The 41060 Writing Shelf is available in two versions. The 41060-00 Writing Shelf mounts in a 19" equipment rack. The 41060-11 Writing Shelf mounts in a 23" equipment rack.

Both shelves are one rack unit high (1.75"). Each provides a storage drawer, a writing surface, and a protected display space for a drawing or data sheet.

The drawer can store meters, test leads, patch cords, jacks, and plugs. It slides easily, without locking, for efficient use. The drawer cover has a transparent plastic overlay for a smooth writing surface. The overlay is also a protective cover for drawings, telephone lists, or any document up to 11 x 17 inches.

The shelves have rounded corners to prevent snagging of clothing or skin.

The mounting brackets are adjustable so that you can install the shelves

- ◆ Flush with the equipment rack
- ◆ Two inches forward from the equipment rack
- ◆ Five inches forward from the equipment rack (standard with -12 option)

The mounting brackets have 1" and 1.25" hole spacing for installing the shelves in equipment racks.

UPDATED


INSTALLATION

The 41060 can be mounted from the front (“Front Mounting”) of the rack or from the back (“Rear Mounting”) of the rack.

FRONT MOUNTING

The shelf comes with the mounting brackets installed for flush mounting to the front of the equipment rack. Refer to Fig. 1.

FIG. 1 - FRONT MOUNTING, 41060



To change the bracket locations:

1. On one side, extend the shelf slide as far as it will go.
2. Push down on the release lever (refer to Fig. 2) and separate the slide from the shelf.
3. Move the inner part of the slide to expose one of the two screws that hold the mounting bracket to the slide.
4. Remove the screw.

CONTINUED . . .


INSTALLATION

5. Move the inner part of the slide to expose the other screw.
6. Remove the screw.
7. Relocate the front of the bottom lip of the mounting bracket either two inches or five inches back from the front of the slide.
8. Attach the bracket to the slide with the two screws.
9. Push the slide back onto the writing shelf.
10. Repeat the steps above for the mounting bracket on the other side of the shelf.

To install the writing shelf:

Mount the shelf to the front of the equipment rack using the hardware provided.

FIG. 2 - RELEASE LEVER LOCATION, 41060




REAR MOUNTING

The -00 and -11 options come with the mounting brackets installed for flush mounting to the front of the equipment rack. The -12 option comes factory set for a 5" extension to the front. The following procedure allows you to remove the brackets and reinstall them so you can mount the shelf to the rear of the equipment rack. Refer to Fig. 3.

UPDATED

INSTALLATION

FIG. 3 - REAR MOUNTING, 41060



To install the writing shelf:

1. On one side, extend the shelf slide as far as it will go.
2. Push down on the release lever (refer to Fig. 2) and separate the slide from the shelf.
3. Move the inner part of the slide to expose one of the two screws that hold the mounting bracket to the slide.
4. Remove the screw.
5. Move the inner part of the slide to expose the other screw.
6. Remove the screw.
7. Repeat the above steps for the mounting bracket on the other side of the shelf.
8. Swap the mounting brackets so that the one that was on the left slide is now on the right slide and the one that was on the right slide is now on the left slide. This is necessary so that the bottom lip of the mounting bracket is against the bottom of the slide. Also, the holes for mounting the brackets to the equipment rack are now at the rear of the slide.

CONTINUED . . .

INSTALLATION

- 9 Position the brackets on the slides for flush, two-inch, or five-inch mounting.
10. Reinstall the screws.
11. Push the slides back on the writing shelf.
12. Mount the shelf to the rear of the equipment rack using the hardware provided.

TECHNICAL SPECIFICATIONS

DESCRIPTION	VALUE
DIMENSIONS	
19"	19" x 12" x 1.75"
23"	23" x 12" x 1.75"
WRITING SURFACE	
19"	17" x 11.25"
23"	21" x 11.25"
DRAWER SPACE	
19"	16" x 11.5" x 1.4"
23"	20" x 11.5" x 1.4"
Loading	50 lbs (fully extended)

NOTES

WARRANTY

LIMITED WARRANTY

The Seller warrants that the standard hardware products sold will be free from defects in material and workmanship and perform to the Seller's applicable published specifications for a period of 18 months for hardware, and 3 months for software, from the date of the original invoice. The liability of the Seller hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned F.O.B. to the Seller's plant, (or, at the Seller's option, refunding the purchase price of such products). In no case are products to be returned without first obtaining permission and a customer return authorization number from the Seller. In no event shall the Seller be liable for any consequential or incidental damages.

Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. The Seller shall make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to custom equipment or products produced to the Buyer's specifications except as specifically stated in writing by the Seller in the contract for such custom equipment.

This warranty is the only warranty made by the Seller with respect to the goods delivered hereunder, and may be modified or amended only by a written instrument signed by a duly authorized officer of the Seller and accepted by the Buyer.

Warranty and remedies on products not manufactured by the Seller are in accordance with warranty of the respective manufacturer. THE SELLER MAKES NO OTHER WARRANTY OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED; AND ALL IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEEDS THE AFORESAID OBLIGATIONS IS HEREBY DISCLAIMED BY THE SELLER.

IN CASE OF DIFFICULTY

If you experience difficulty with this equipment, check the following, as appropriate:

1. Switch settings
2. Signal levels
3. Software configuration
4. Connections between Dantel's equipment and your equipment.

If there is still a problem, substitute equipment that is known to be good. For additional assistance, call Dantel's Technical Field Service Department weekdays, 6 A.M. to 5 P.M. pacific time:

1-800-4DANTEL (1-800-432-6835).

If a thorough checkout shows a piece of equipment has malfunctioned, you may return it to the factory. For repairs and emergency replacements, obtain a Return Material Authorization (RMA) number from the Customer Service Representative at **1-800-4DANTEL (1-800-432-6835)**.

To ensure expedient processing of your order, provide a purchase order number and shipping and billing information when requesting an RMA number. Also, when the units are returned to Dantel, include a description of the failure symptoms for each unit returned. Send defective equipment to:

Dantel, Inc. • 2991 North Argyle Avenue • Fresno, California 93727-1388

