


# 46000

# DANTEL UTILITY



## Table of Contents

Ordering Information .....	2
General Description .....	2
Installation .....	3
Warranty .....	6

### About this Practice:

This practice has been reissued to:

- Meet ISO 9001 requirements.

**Reissued Practices:** Updated and new content can be identified by a banner in the right margin.

**Issue date: June 1998**

UPDATED

### CAUTION

- Install or remove modules from the shelf only when the power is off. If you install a module in the shelf with the power on, the internal circuitry may suffer damage and the product warranty will be void.
- Remove and install circuit boards only in a static-safe environment (use antistatic wrist straps, smocks, footwear, etc.).
- Keep circuit boards in their antistatic bags when they are not in use.
- Do not ship or store circuit boards near strong electrostatic, electromagnetic, magnetic, or radioactive fields.
- For more complete information on electrostatic discharge safety precautions, refer to Bellcore™ Technical Reference # TR-NWT-000870.

# ORDERING INFORMATION

**NOTE:** This section lists the different options available for this product. To order any of the available options, contact Dantel Inside Sales through our toll-free number, **1-800-432-6835**.

OPTION NUMBER	FEATURES
A22-46000-X2	Dantel Utility

## GENERAL DESCRIPTION

The Dantel Utility software is a program for Windows 3.1, Windows 95 or Windows NT 3.51 that provides:

---

### Dantel contact information

Contains the address, phone numbers and fax number of Dantel headquarters.

---

### Contact information for your Dantel representative

Contains your regional representative's name, address, telephone numbers and fax number.

---

### Measurement and temperature conversion

Converts measurements, temperature and BTUs into other measurements to your specified decimal precision.

---

### A memo pad

The memo pad lets you write notes as long as you want.

---

### A 12-month calendar

You can select by month and by year, from 1890 to 2099, and you can go to the current date when you click the Show Current Date button.

---

### A glossary of industry acronyms

Lists industry acronyms in alphabetical order. You can go to a particular group of acronyms or add your own when you click the Editor button.

---

### Pin interface diagrams

You can select, view and print pin diagrams for RJ connections, RS-232, RS-449, RS-530 and the V.35 Interface.

---

### A directory of Dantel sales representatives

Lists all current Dantel sales representatives in alphabetical order.

You can go to the appropriate function by clicking on the folder tabs at the top of the window.

Call your area Dantel representative to get a copy of this free and useful utility software.

# INSTALLATION

This software can be installed on an IBM-compatible computer equipped with the following:

- ◆ Windows 3.1, Windows 95, or Windows NT 3.51
- ◆ 8M of memory (16M for Windows NT)
- ◆ VGA/high-resolution color (recommended), monochrome, or LCD monitor
- ◆ One serial port
- ◆ One 3.5" diskette drive
- ◆ One hard disk drive

## INSTALLATION

### TO INSTALL THE SOFTWARE ON WINDOWS 3.1 AND WINDOWS NT:

1. Open Windows.
2. Open the Program Manager, if it is not already open.
3. Insert the disk into one of the diskette drives of your computer.
4. Open the *File* menu.
5. Click the *Run* command.
6. In the Command Line type the letter of the drive where you installed the disk (either drive A or B). Then type a colon, a backslash (\) and setup.exe. For example, type **B:\setup.exe**
7. Click OK.
8. Follow the instructions on the screen for installing the software. The software will be installed in the default directory of **C:\Dantel\Utility**, unless you specify a different directory.

---

**CAUTION:** *Make sure you install the program in a new directory. Do not install the program in an existing directory.*

---

9. When the installation is complete, store the disk in a safe place.

### TO INSTALL THE SOFTWARE ON WINDOWS 95:

1. Open Windows 95.
2. Click the *Start* button.
3. Insert the disk into one of the diskette drives of your computer.
4. Click the *Run* command.
5. In the Command Line type the letter of the drive where you installed the disk (either drive A or B). Then type a colon, a backslash (\) and setup.exe. For example, type **B:\setup.exe**
6. Click OK.

CONTINUED . . .

# INSTALLATION

7. Follow the instructions on the screen for installing the software. The software will be installed in the default directory of **C:\Dantel\Utility**, unless you specify a different directory.

---

**CAUTION:** *Make sure you install the program in a new directory. Do not install the program in an existing directory.*

---

8. When the installation is complete, store the disk in a safe place.

## OPENING THE SOFTWARE

### IN WINDOWS 3.1 AND WINDOWS NT:

1. Open Windows.
2. Open the Program Manager, if it is not already open.
3. Open the *Dantel Software* group window, if it is not already open.
4. Double-click the *Utility* icon to start the program.

### IN WINDOWS 95:

1. Open Windows 95.
2. Click the *Start* button.
3. Click *Programs*.
4. Click *Dantel Software*.
5. Double-click the *Utility* icon to start the program.

# NOTES

# WARRANTY

## LIMITED WARRANTY

The Seller warrants that the standard hardware products sold will be free from defects in material and workmanship and perform to the Seller's applicable published specifications for a period of 18 months for hardware, and 3 months for software, from the date of the original invoice. The liability of the Seller hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned F.O.B. to the Seller's plant, (or, at the Seller's option, refunding the purchase price of such products). In no case are products to be returned without first obtaining permission and a customer return authorization number from the Seller. In no event shall the Seller be liable for any consequential or incidental damages.

Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. The Seller shall make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to custom equipment or products produced to the Buyer's specifications except as specifically stated in writing by the Seller in the contract for such custom equipment.

This warranty is the only warranty made by the Seller with respect to the goods delivered hereunder, and may be modified or amended only by a written instrument signed by a duly authorized officer of the Seller and accepted by the Buyer.

Warranty and remedies on products not manufactured by the Seller are in accordance with warranty of the respective manufacturer. **THE SELLER MAKES NO OTHER WARRANTY OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED; AND ALL IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEEDS THE AFORESAID OBLIGATIONS IS HEREBY DISCLAIMED BY THE SELLER.**

## IN CASE OF DIFFICULTY

If you experience difficulty with this equipment, check the following, as appropriate:

- 1. Switch settings**
- 2. Signal levels**
- 3. Software configuration**
- 4. Connections between Dantel's equipment and your equipment.**

If there is still a problem, substitute equipment that is known to be good. For additional assistance, call Dantel's Technical Field Service Department weekdays, 6 A.M. to 5 P.M. pacific time:

**1-800-4DANTEL (1-800-432-6835).**

If a thorough checkout shows a piece of equipment has malfunctioned, you may return it to the factory. For repairs and emergency replacements, obtain a Return Material Authorization (RMA) number from the Customer Service Representative at **1-800-4DANTEL (1-800-432-6835)**.

To ensure expedient processing of your order, provide a purchase order number and shipping and billing information when requesting an RMA number. Also, when the units are returned to Dantel, include a description of the failure symptoms for each unit returned. Send defective equipment to:

**Dantel, Inc. • 2991 North Argyle Avenue • Fresno, California 93727-1388**

