

COLORED BUTTONS

FOR USE IN KEY TELEPHONE SETS, CALL DIRECTORS, CARD DIALERS, SEPARATELY MOUNTED KEYS, AND 400-TYPE KEY MOUNTINGS

1. GENERAL

- 1.01 This section shows ordering information on colored buttons used in keys.

TABLE A

SELECTION OF COLORED BUTTONS AND USE IN SETS

Type Set or Key	Color of Button	Piece Part Number
540 and 560 series telephone sets; 6040- and 6041-type keys (Round buttons only)	Clear	P-12A856
	Red	P-25E308
	Green	P-25E378
	Blue	P-25E379
	Yellow	P-25E380
	Amber	P-25E381
560 and 1560 series telephone sets (Square buttons only)	Clear	P-25E097
	Red	P-25E299
	Green	P-25E382
	Blue	P-25E383
	Yellow	P-25E384
	Amber	P-25E385
Call Directors, 662, 1662 telephone sets; 6050 and 6051 keys; and 400 key mountings (Square buttons only)	Clear	P-10E864
	Clear with stripe	P-12E728
	Red	P-11E028
	Green	P-11E912
	Blue	P-11E913
	Blue with stripe	P-26E454
	Yellow	P-11E914
	Amber	P-11E915
	Orange	P-26E828
	Milk white (translucent)	P-26E829
	Purple	P-26E830