

OPEN WIRE

NUMBERING OF PIN POSITIONS

1. GENERAL

1.01 This practice contains illustrations showing preferred numbering for various types of crossarms.

2. PIN POSITIONS

2.01 Pin positions are numbered from left to right; with your back to the central office, or facing ascending pole numbers.

2.02 The following illustrations shall be followed unless other numbering plans are established for certain lines.



Figure 1. 2-Pin Crossarm




Figure 2. 4-Pin Crossarm




Figure 3. 6-Pin Crossarm




Figure 4. 8-Pin Crossarm (Carrier Design)




Figure 5. 10-Pin Crossarm




Figure 6. 16-Pin Crossarm