

20-BUTTON, PUSHBUTTON DIAL, DESK TELEPHONES

CIRCUIT LABELS

1. GENERAL

1.01 This document covers the 20-button, pushbutton dial, desk telephones. (See Figure 1.) Circuit labels for different models of 20-button, pushbutton dial, desk telephones are included. (See Table A.)



AW 86-348

Figure 1: 20-Button, Pushbutton Dial, Desk Telephone

1.02 This section is reissued to provide the latest issue of circuit labels for the following 20-button, pushbutton dial, desk telephones:

- (a) Model 2831, Types 42 and 46
- (b) Model 2831, Type 76

1.03 For additional information on description and installation of the telephones, refer to Section 50-831-103. A replacement parts list and an exploded-view drawing for the telephones are contained in Section 50-831-104. Related documents of the ITT Telephone Apparatus Practices Manual provide information on components.

1.04 The Model 2831 desk telephones are identified by a code number stamped in ink on the bottom of the base plate. Refer to Section 50-831-103 of the Telephone Apparatus Practices Manual for ordering information and for an explanation of each code number.

1.05 The Model 2831 desk telephones are 20-button, pushbutton dial, anti-sidetone type units that operate efficiently over a wide range of loop resistances and line impedances. These telephones are designed for use with key telephone systems, such as the ITT 1A2 System, where several telephones have access to the same lines, CO trunks, or intercom lines.

TABLE A
LIST OF CIRCUIT LABELS

MODEL NO	TYPE NO	FIGURE NO
2831	42, 46	2
2831	76	3

AW 86-399

