

## TRANSPARENT WINDOWS FOR TURNBUTTON AND KEY TELEPHONE SETS IDENTIFICATION

### 1. GENERAL

1.01 This section contains information on transparent windows used on turnbutton and key telephone sets (Fig. 1).

1.02 This section is reissued to:

- Show transparent window forms with preprinted information is no longer available
- Add information on clear transparent window forms.

Since this section covers a general revision, arrows ordinarily used to indicate changes have been omitted.

### 2. IDENTIFICATION

2.01 Table A lists the recommended replacements for the old forms.

2.02 The new forms are perforated on continuous clear acetate without preprinted information, therefore it is necessary to order an appropriate station number card form. Refer to Section 501-150-100 for additional information.

2.03 Forms are ordered by the package, with 1000 cards per package.


2.04 Order as follows;

- (a) (Quantity) Form E-10374


**Note:** This form is used with rotary dial equipped telephone sets.

- (b) (Quantity) Form E-10375

**Note:** This form is used with TOUCH-TONE® dial equipped sets.



E-10374



E-10375

Fig. 1—New Transparent Windows

### NOTICE

Not for use or disclosure outside the  
Bell System except under written agreement

◆ TABLE A ◆

RECOMMENDED REPLACEMENTS FOR  
OLD TRANSPARENT WINDOW FORMS

FORMS		INTENDED USE
OLD FORM	REPLACED BY FORM	
E-2959	E-10374	On each station in a multistation system
E-4609		To indicate which line is connected to the set as determined by position of the turnbutton
E-4610		To indicate ON or OFF position of the turnbutton.
E-4611		To indicate ON or OFF position of headset
E-4612		To indicate when ringer is ON or OFF
E-4613		To indicate when an extension is connected to or excluded from the line
E-4614		To indicate whether central office or local line is connected to the set
E-4615		To indicate whether central office or private line is connected to the set
E-4809		Same as 4614 except for PRINCESS <sup>®</sup> set
E-4810		To indicate which central office line is connected to the PRINCESS set
E-5414	E-10375	On TOUCH-TONE <sup>®</sup> sets and TRIMLINE <sup>®</sup> sets in multistation systems