

SERVICE
513B AND 513BM TELEPHONE SETS

1. GENERAL

1.01 This section provides connector information for the 513B and the 513BM telephone sets.

1.02 This section is reissued to:


- Add information on the 513BM modular telephone set

- Change mounting card of 513B telephone set from D10N-61 to D10N-87

- Add Fig. 2.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement



- NOTES:
1. FOR ATTENDED OPERATION MOVE (O-W) LEAD FROM E1 TO TERMINAL 9.
 2. LINE SWITCH SEQUENCE, HANDSET REMOVED.
bc MAKES
de MAKES
ab BREAKS
gf BREAKS
 3. TO SILENCE RINGER PERMANENTLY DISCONNECT (BK) RINGER LEAD. INSULATE AND STORE.
 4. H4DU CORD NOT FURNISHED WITH TELEPHONE SET.

Fig. 2—513BM Modular Telephone Set, Connections