

**SPEAKERPHONE SYSTEM—3-TYPE**  
**500R/S TELEPHONE SET**  
**CONNECTIONS AND MAINTENANCE**

**1. GENERAL**

**1.01** These sets are supplied factory-wired for use with 3-type speakerphone. See Section 502-510-407 for set wiring and ringer connections.

**1.02** This section contains speakerphone connection information formerly found in Section 512-620-401, Issue 3.

**2. CONNECTION INDEX**

Fig. 1—500R/S Telephone Set—Speakerphone Connections

**3. MAINTENANCE**

**3.01** Refer to the appropriate section for maintenance information for the 500R/S telephone set. See Section 512-620-200 for maintenance of speakerphone components used with this set.

SECTION 512-620-410




Fig. 1—500R/S Telephone Set—Speakerphone Connections